

Panel upgrade Part 2 Lab

Program: Electrician Technician

Course: EL190

Objective: Under the supervision of your instructor, you should be able to do the following:

• Properly upgrade a new panel

Lab Equipment: N/A

Required Tool:

- 1 Drill
- 1 Ladder 6ft
- 1 Tape measure
- 1 Flathead screwdriver
- 1 Phillips's screwdriver
- 1 Strippers
- 1 Utility knife

Materials:

- Panel
- 20' 14/2 Romex
- 20' 14/3 Romex
- 5 − ½" 2 screw NM wire connectors
- 6' #8 armored ground
- 1 Armored ground clamp

Safety (PPE):

- Safety glasses/goggles
- Hard hat

Resources: N/A

Required Time: One Day

Shop Maintenance:

- All work will cease 20 minutes prior to the end of class.
- All work areas must be cleaned.

This document contains proprietary information of IEC Corporation and its affiliated entities (collectively, "IEC") and is intended solely for use by IEC employees and students. Such proprietary information may not be used, reproduced, or disclosed to any other parties for any other purpose without the expressed written permission of IEC.

Revised 04/22/2019



- Tools and equipment must be cleaned and returned to the designated areas (cage, tool room, cabinets etc.)
- Any broken or missing tools must be reported immediately.
- Tools and equipment are students' responsibility

Procedures: Eye protection must always be worn. Refer to code book as much as possible during the lab.

Step 1, Day 1:

Perform the "Panel upgrade lab part 1

Step 2 Day 2

- Make sure power is off to the panel.
- Start removing each wire that is in the panel and using the number marker to identify the wire. On a separate piece of paper write the number and what the breaker operates
- Remove the remaining wires for the terminal
- · Remove the wires from the panel. Do not damage the wires as they will be reinstalled on the new panel.
- Once ground and all items have been removed, take the old panel off and install the new panel
- Run a #4 armored ground from the panel to the ground rod.
- Insert appropriate connectors for the wire to enter the panel.
- Reinstall the original wires making sure not to lose the wire markings.
- Start with terminating the grounds, then the neutrals and then finally your lines to the breakers.
- Label the new panel on a piece of paper using the markers as your guide.
- Assure that the panel is phased properly. (Phase = make sure any three wire has the black on buss A and the red on Buss B)