



Enabling ChatterBox Cloud

You may choose to enable cloud or MQTT on any ChatterBox Communicator (T-Decks). By doing this, your communicator can become a bridge for your cluster, enabling your cluster to reach anywhere with internet. You may even run any communicator *exclusively* on cloud/MQTT if you choose.

ChatterBox uses MQTT as a cloud bridge. MQTT is a lightweight messaging protocol, often used for IOT. ChatterBox Supports:

- MQTT 3.1.1
- MQTT/TCP
- 2.4 G WiFi Only
- Tested with shiftr.io

*ChatterBox does not yet support TLS, but remember, it's already **end-to-end encrypting** and **digitally signing** your payloads no matter how the message arrives.*



1. Settings / WiFi / Add Connection

2. Settings / Mesh Cloud / Setup Cloud



Once connected, your device will automatically make use of MQTT, in addition to LoRa for connecting with other devices in your cluster or channel.

You will need an MQTT service. An inexpensive (or free) option is shiftr.io

