GAME - Team UPDATE - 2012-02-03 Robot Rules Toperator Console

Note: The version of the Driver Station released at Kickoff has not changed. This Rule change is to bring the Rule in line with the current version.

Power Distribution **1** [R37]

Items specifically *prohibited* from use on the Robot include:

- 1. circuit breakers used on the Power Distribution (PD) Board that are different from the Snap Action breakers provided in the KOP , and
- 2. PD Boards and/or fuse panels other than the single PD Board provided in the KOP since 2009, and.

Operator Console **1** [R80]

The Driver Station software provided on the Kit of Parts website is the only tool permitted to specify and communicate the operating mode (i.e. Autonomous/Teleop) and operating state (enable/disable) to the Robot. The Driver Station software must be revision 11.30.11.00 01.07.12.00 or newer.