

Control Valve Operational Manual

Equipment ID: 56680

Revision Date: 2025-07-02

Authorized By: Architect David Kim

1. Equipment Specifications

Parameter	Specification
Manufacturer	FlowMaster Industries
Model	FM-CV-200X
Size	2" (DN50)
Pressure Rating	300 PSI
Temperature Range	-20°C to 180°C
Flow Rate	0–800 L/min

2. Schematic Diagram

[DIAGRAM: 8]

3. Operating Procedures

3.1 Startup Sequence

1. Pre-Startup Checks

- Verify that all maintenance work is complete and lockout/tagout devices are removed.
- Ensure all personnel are clear of the valve and associated piping.
- Inspect the valve for visible damage or leaks.
- Confirm that the valve is in the ‘Closed’ position.

2. System Initialization

- Power on the control system panel.
- Check that all relevant sensors (pressure, temperature, position) are online and reading within ambient ranges.
- Confirm upstream and downstream isolation valves are in the correct positions (typically open).

3. Valve Operation

- Using the HMI (Human-Machine Interface), select ‘Remote’ or ‘Automatic’ mode as required.

- Gradually open the control valve to the desired setpoint (typically 10–20% open for initial flow).
- Monitor the following sensor readings:
 - **Valve Position Indicator:** Should match HMI command.
 - **Upstream Pressure:** Should not exceed 300 PSI.
 - **Downstream Pressure:** Should rise as flow initiates.
 - **Flow Rate:** Should increase proportionally (target: 0–800 L/min).

4. Stabilization

- Allow system to stabilize for 2–5 minutes.
- Adjust setpoint as required to achieve process flow.

3.2 Normal Operation Monitoring

- **Key Parameters & Acceptable Ranges:**
 - **Valve Position:** 0–100% (as per process demand)
 - **Upstream Pressure:** 50–300 PSI
 - **Downstream Pressure:** 0–250 PSI
 - **Temperature:** -20°C to 180°C
 - **Flow Rate:** 0–800 L/min
- **Actions:**
 - Monitor for abnormal noises, vibrations, or leaks.
 - Check for erratic valve movement or unresponsive behavior.
 - Log all readings every 4 hours in the operations logbook.

3.3 Shutdown Procedure

1. **Initiate Shutdown**
 - Gradually reduce flow setpoint to minimum.
 - Close the control valve fully via HMI.
 - Confirm valve position indicator reads ‘Closed’.
 2. **System Isolation**
 - Close upstream and downstream isolation valves.
 - Depressurize the line if required (follow plant depressurization procedure).
 3. **Power Down**
 - Switch control system panel to ‘Off’.
 - Apply lockout/tagout devices if maintenance is required.
-

4. Safety Precautions

4.1 Lockout/Tagout (LOTO) Procedures

- Isolate electrical and pneumatic supplies before maintenance.
- Apply LOTO devices to all energy sources.

- Verify zero energy state before commencing work.

4.2 Personal Protective Equipment (PPE)

- Safety helmet
- Chemical-resistant gloves
- Safety goggles/face shield
- Flame-resistant coveralls
- Steel-toe boots
- Hearing protection (if in high-noise area)

4.3 Emergency Stop Locations

- Main control panel (adjacent to valve skid)
- Local emergency stop button (red, labeled, within 2 meters of valve)
- Plant-wide emergency shutdown system (refer to plant map)

5. Troubleshooting Guide

Symptom	Possible Cause	Corrective Action
No Flow	Valve Closed	Open Valve
	Actuator Failure	Inspect/repair actuator
	No Power to Valve	Check electrical supply
High Pressure	Blockage	Check upstream line
	Downstream Valve Closed	Open downstream valve
	Faulty Pressure Sensor	Calibrate/replace sensor
Low Flow	Partial Blockage	Inspect/clean valve internals
	Insufficient Upstream Pressure	Check supply system
Valve Stuck	Mechanical Obstruction	Remove obstruction
	Actuator Malfunction	Service actuator
Leakage	Damaged Seal	Replace seal
	Loose Flange Bolts	Tighten bolts to spec
Erratic Operation	Control Signal Fault	Check wiring/HMI settings
	Air Supply Fluctuation	Stabilize air supply

6. Maintenance Schedule

Frequency	Task Description	Responsible	Next Due Date
Daily	Visual inspection for leaks, damage, or noise	Operator	2025-07-03
	Log sensor readings	Operator	2025-07-03

Frequency	Task Description	Responsible	Next Due Date
Weekly	Check actuator and positioner function	Technician	2025-07-09
	Inspect electrical and pneumatic connections	Technician	2025-07-09
Monthly	Full valve stroke test	Engineer	2025-08-02
	Inspect and lubricate moving parts	Engineer	2025-08-02
	Calibrate sensors and position indicators	Engineer	2025-08-02

7. Record Keeping Requirements

- All operational logs (startup, shutdown, monitoring) must be recorded in the plant's digital logbook.
 - Maintenance activities must be documented in the CMMS (Computerized Maintenance Management System) with date, time, and personnel signature.
 - All incidents, troubleshooting actions, and corrective measures must be reported to the shift supervisor and logged.
 - Retain records for a minimum of 5 years as per plant policy.
-