Status Monitoring Tasks

Example Program 1 — Status Report Inquiry

The commands you send are in BOLD, (followed by <CR><LF>) the 5071A's responses are in italics. If you make a mistake (i.e., generate an error # at the scpi prompt) type "*cls" followed by <CR><LF> (Return Line Feed).

Program Dialog	Task Function
SYST:PRINT?	Request an operating status report.

```
MJD    48587 21:03:42
CBT  ID:  6-temp
Status summary: Operating normally
Power source: AC
Log status: Empty


Freq Offset:         0e-15          Osc.control:        -1.67 %
RF amplitude 1:     20.2 %          RF amplitude 2:      19.9 %
Zeeman Freq:      39949 Hz          C-field curr:      12.137 mA
E-multiplier:       1870 V          Signal Gain:         28.8 %


CBT Oven:            6.2 V          BT Oven Err:         0.00 C
Osc. Oven:          -8.8 V          Ion Pump             0.2 µA
HW Ionizer:          1.0 V           Mass spec:          9.1 V
SAW Tuning:          3.5 V          DRO Tuning:          6.8 V
87MHz PLL:          -0.8 V          µP clock PLL:        2.9 V
+12V supply:        12.3 V           -12V supply:      -12.4 V
+5V supply:          5.3 V           Thermometer:        35.0 C


scpi >
```

Example Program 2 — Print Log Request

Program Dialog	Task Function
DIAG:LOG:PRINT?	Print log (empty !)

```
Log status: Empty


<scpi >
```