NOTE: Please respond problems you meet to us, our engineer will help analyse the problem for you . And in case that there is no need to upgrade the firmware, please don't reset the firmware.

- 1. Copy "firmwareResetV1.hex" to the desktop
- 2. Electricify the motherboard and connect to computer with USB, then open the computer device manager to confirm the COM, for example, my computer displays COM 6.
 - ▲ 導 端口 (COM 和 LPT)

 USB-SERIAL CH340 (COM6)
- 3. Open the tool folder, then open "avrdudess.exe".
- 4. Related parameters of configureation as below.



