DIY Eco Resin Kit

QUICK START & TERRAZZO GUIDE

KAIZEN - MINDFUL CRAFTING

⚠️ SAFETY FIRST!

- **Nitrile Gloves:** Protects skin from raw resin liquid/powder contact to prevent dryness and irritation.
- **Dust Mask:** Shields lungs from fine mineral dust when mixing raw powder and during wet sanding.
- **Work Area:** Cover workspace with paper or plastic to protect against spills.
- *We recommend consulting with a doctor if you have lung or skin sensitivities as using resin carries risk that can cause respiratory or skin irritation.*

📦 WHAT'S INCLUDED

- Safety gear (Mask & Gloves)
- Pre-made Terrazzo Chips
- 2x Mixing Cups
- 1x Sandpaper sheet
- Necklace Cord & Clasp
- Eco Resin (Base Powder)
- Silicon Pendant Mould
- Toothpick / Stir Stick
- 1x Finishing Wipe

📌 **Not included: Tap water and pliers.**

Tips & Techniques

🥣 1. The Mix (Precision)

- **Ratio is King:** Always follow 3:1 powder to water. Pour water little by little.
- **Small Batches:** Only mix what you can pour in 10 mins. Stop if thick to avoid lumps.
- **The Sift:** Stir slowly until like pancake batter. Too liquid takes long to cure; too thick traps bubbles.

🪣 2. Pour & Vibrate

- **The High Pour:** Pour in a thin stream from high up; this "stretches" the resin and pops bubbles before they hit the mould.
- **Tap-Tap-Tap:** Tap sides of the mould firmly once poured to force hidden bubbles to surface.

✨ 3. The Finish

- **The Heat:** The mould will get warm—this is completely normal!
- **De-moulding:** Wait 20–30 minutes. If soft or "damp," wait another 10 minutes.

Step-by-Step Instructions

1. **Mix the Base:** Pour half the eco resin powder into your first mixing cup. Add a bit of water. Stir thoroughly with your toothpick until smooth and lump-free.
2. **Add Terrazzo Chips:** Pour some of your terrazzo chips into the mixed resin.
3. **Pour into Mould:** Slowly pour the mixture into the pendant silicone mould. Tap the mould gently on the table to release trapped air bubbles.
4. **Demould:** Allow the pendant to cure completely (typically 30–40 minutes until hard and cool to touch) and pop it out of the mould.
5. **Wet Sand for Terrazzo Effect:** Pour water onto sandpaper and sand the pendant's face in smooth circles to reveal colourful terrazzo chips.
6. **Clean & Polish:** Wipe away excess slurry using the included wipe and a splash of water, then dry thoroughly.
7. **Assemble Necklace:** Open the clasp with your hand (can use pliers - not included - if necessary), put the resin cast in the middle then pinch back to secure. Thread the jump necklace cord through the finding.
8. **Your terrazzo necklace is ready to wear!**

🌐 **Website: kaizen.classbento.com** 📸 **Instagram: www.instagram.com/craftskaizen**