Connection NANO to other PCB's

Pin NANO	Board	NANO PortName	NANO		ccs		CVS		Divider		Power-MT3608
			Function	Pin Name Source							
	Connector				Conn_CCS		Conn_CVS		5V to 3.3V		SW15V_Ubat?
D1 / TX		PD1	USB / BLE4								
D0 / RX		PD0	USB / BLE4								
Reset		PC6									
Gnd			Power		J1-1/J2-4	Gnd	J1/J2-Pin1	Gnd	J1-2/J-10	Gnd	J2-1
D2		PD2	ISR	pin_ENC2_A							
D3		PD3	ISR	pin_ENC1_A							
D4		PD4	GPIO	pin_ENC1_B							
D5		PD5	GPIO	pin_ENC2_B							
D6		PD6	GPIO	pin_ADC_CS			J1-Pin2				
D7		PB7	GPIO	pin_DAC_CS			J1-Pin3				
D8		PB0	GPIO	not used							
D9		PB1	GPIO	TFT_CS					J1-3	R_CS_G1	
D10		PB2	GPIO	TFT_DC					J1-4	R_DC1	
D11		PB3	SPI MOSI	SPI_MOSI			J1-Pin5		J1-5	R_MOSI1	
D12		PB4	SPI MISO	SPI_MISO			J1-Pin6		J1-6	R_MISO1	
D13		PB5	SPI SCK	SPI_SCK			J1-Pin4		J1-7	R_SCK1	
A0 / D14		PC0	GPIO	pin_E_NEG			J4-Pin2	N-devices			J2_1
A1 / D15		PC1	GPIO	pin_E_POS			J4-Pin3	P-devices			J2_2
A2 / D16		PC2	GPIO	pin_CV_SW	J2-3						
A3 / D17		PC3	GPIO	pin_EB	J2-2	P-devices					
A4 / D18		PC4	I2C SDA	I2C_SDA	J1-2						
A5 / D19		PC5	I2C SCL	I2C_SCL	J1-3						
A6		ADC[6]	only analog	not used							J2-3
A7		ADC[7]	only analog	not used							
+5V					J1-2	+5V			J1-1	+5V	
Reset		PC6									
Gnd			Power								
Vin		6.7-12V	Power								