

INTAKE VALVE CLEARANCE ADJUSTMENT

Remove the valve lifter and shim . Clean the valve shim contact area in the valve lifter [1] with compressed air.



Measure the shim [1] thickness and record it. NOTE:

• Fifty-one different shim thicknesses are available in increments of 0.025 mm (from 1.200 mm to 2.450 mm).





Calculate the new shim thickness using the equation below.

A = (B - C) + D

A: New shim thickness

B: Recorded valve clearance

C: Specified valve clearance

D: Old shim thickness

NOTE:

- Make sure of the correct shim thickness by measuring the shim with the micrometer.
 Reface the valve seat if carbon deposits result in a calculated dimension of over 2.450 mm.

Install newly selected shims on the valve retainers. Install the valve lifter and camshaft.

Rotate the crankshaft counterclockwise several times and recheck the valve clearances.







1.85 mm



1.875 mm