REMOVAL/INSTALLATION Page 1 of 1

REMOVAL/INSTALLATION

Remove the gearshift arm

! MT model only:

Remove the left rear cover bolts [1], left rear cover [2] and drive chain guide plate [3]. Release the sidestand wire clip [4] and sidestand wire [5] from the left rear cover. Installation is in the reverse order of removal.

TORQUE:	
Left rear cover bolt:	
Left rear cover bolt: 12 N·m (1.2 kgf·m, 9	lbf·ft)

NOTE:

- Align the chain guide plate holes with the left rear cover bosses.
- Route the wires properly

