CRANKCASE BREATHER


Page 1 of 2

## **CRANKCASE BREATHER**

Check the air cleaner housing drain hoses [1]. **NOTE:** 

 Service if the deposits level can be seen in the drain hose.

If necessary, remove the drain plugs [2] from the drain hoses and drain the deposits into a suitable container.
Reinstall the plugs securely.



CRANKCASE BREATHER

Page 2 of 2

