REMOVAL/INSTALLATION Page 1 of 2

REMOVAL/INSTALLATION

Remove the following from the front fender:

- Bolt [1]Nut [2]
- Brake hose clamp [3]
- Front wheel speed sensor wire clamp [4]

Release the front wheel speed sensor wire clip [5] from the fender A stay collar [6].
Remove the long socket bolts [7], short socket bolts [8] and front fender [9].
Remove the collars [10], rubber cushion A [11] and rubber cushion B [12] from the front fender.
Remove the front side reflector nuts [13] and front side reflectors [14] from the fender A stay collar.
Installation is in the reverse order of removal.

TORQUE:

Front side reflector nut:

1.8 N·m (0.2 kgf·m, 1.3 lbf·ft)

· Route the wire and hoses properly

