REMOVAL/INSTALLATION Page 1 of 1

## **REMOVAL/INSTALLATION**

## Remove the following:

- Trim clips [1]
- Socket bolt [2]
- Regulator/rectifier cover [3]

Installation is in the reverse order of removal.

