REMOVAL/INSTALLATION Page 1 of 1

REMOVAL/INSTALLATION

Remove the front cowl.

Remove the windscreen adjust rail bolts [1] and windscreen adjust rail [2].

Installation is in the reverse order of removal.

NOTE:

- Check the windscreen adjustment for smooth operation. Apply grease to the slider guides if there is any unsmooth or heavy operation.
- If there is an excessive looseness at the windscreen slider or if the windscreen falls down in riding by the sliding are worn, replace the guides as new ones.

