DISASSEMBLY/ASSEMBLY

Page 1 of 1

## DISASSEMBLY/ASSEMBLY

Disassemble and assemble the rear wheel as shown in the following illustration.

Apply locking agent to the rear brake disk bolt and pulser ring bolt threads.

