
REMOVAL/INSTALLATION Page 1 of 2

## REMOVAL/INSTALLATION

Remove the following:






Remove the following:

- Socket bolts [1]Trim clips [2]

Disconnect the USB socket [3] and accessory socket 2P (Black) connector [4]. Remove the tank front cover [5].



REMOVAL/INSTALLATION Page 2 of 2

Remove the USB socket box [1] by releasing its tabs [2] from the tank front cover [3]. Remove the collar [4].
Installation is in the reverse order of removal.

TORQUE:

Upper deflector socket bolt (long):
| 0.54 N·m (0.06 kgf·m, 0.4 lbf·ft)

• Install the USB socket box as shown.

