
BODY PANEL LOCATIONS Page 1 of 1


BODY PANEL LOCATIONS



- [1] Windscreen
- [2] Windscreen stay
- [3] Windscreen adjust rail
- [4] Front cowl
- [5] Front fender
- [6] Under cover
- [7] Inner cover
- [8] Side cover
- [9] Clutch EOP sensor cover (DCT model)

Deflector cover (MT model)

- [10] Right rear engine cover
- [11] Pillion step
- [12] Muffler/exhaust pipe
- [13] Main seat
- [14] Pillion seat
- [15] Rear center cowl
- [16] Middle cowl
- [17] Rearview mirror
- [18] Rear fender A
- [19] Rear fender B
- [20] Regulator/rectifier cover



- [21] Rear side cowl
- [22] Seat catch hook/seat lock cylinder
- [23] Sidestand
- [24] Mainstand
- [25] Main step
- [26] Heel guard
- [27] Left rear cover
- [28] Seat rail
- [29] Tank front cover
- [30] Rear carrier

BODY PANEL REMOVAL CHART