ED, FO, KO, U

ED, FO, KO, U

Perform the Pre-ride inspection in the Owner's Manual at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.

The following items require some mechanical knowledge. Certain items (particularly those marked * and **) may require more technical information and tools. Consult a dealer.

		FREQUENCY (NOTE 1) NOTE 1 000 L 1 10 01 00 10 ANNUAL REGULAR RE									DEEED TO
ITEMS		NOTE	x 1,000 km	1	12	24	36		CHECK	REPLACE	PAGE
			x 1,000 mi	0.6	8	16	24	32			
*	FUEL LINE				I		I	ı	I		-
*	THROTTLE OPERATION					I		I	I		-
*	AIR CLEANER	NOTE 2				R		R			-
	CRANKCASE BREATHER	NOTE 3			C	С	C	С			-
*	SPARK PLUG							R			-
*	VALVE CLEARANCE							-			-
	ENGINE OIL			R	R	R	R	R	R		-
	ENGINE OIL FILTER			R		R		R			-
	CLUTCH OIL FILTER	NOTE 5		R		R		R			-
*	ENGINE IDLE SPEED					I	-	I	I		-
	RADIATOR COOLANT	NOTE 4				I	ı	I	I	3 years	-
*	COOLING SYSTEM					I	ı	I	I		-
*	SECONDARY AIR SUPPLY SYSTEM					ı		I			-
*	EVAPORATIVE EMISSION CONTROL SYSTEM					I		I			-
	DRIVE CHAIN		EVERY 1,000 km (600 mi) I, L							-	
	DRIVE CHAIN SLIDER				ı	ı	ı	I			-
	BRAKE FLUID	NOTE 4				I		I	I	2 years	-
	BRAKE PADS WEAR				I		I	I			-
	BRAKE SYSTEM							I			-
	BRAKE LIGHT SWITCH					I		ı			-
*	BRAKE LOCK OPERATION	NOTE 5						ı			-

ED, FO, KO, U

	HEADLIGHT AIM			1	ı		1	l	-
	CLUTCH SYSTEM	NOTE 6		ı	ı	ı	ı	I	-
	SIDESTAND			ı	ı	ı	ı	I	-
*	SUSPENSION			ı	ı	ı	ı	I	-
*	NUTS, BOLTS, FASTENERS			I	I	I	I	I	-
**	WHEELS/TIRES				ı		I	I	+
**	STEERING HEAD BEARINGS			I	l		I	I	+

^{*} Should be serviced by a dealer, unless the owner has proper tools and service data and is mechanically qualified.

Honda recommends that a dealer should road test your motorcycle after each periodic maintenance is carried out. NOTES:

- 1. At higher odometer readings, repeat at the frequency interval established here.
- 2. Service more frequently when riding in unusually wet or dusty areas.
- 3. Service more frequently when riding in rain or at full throttle.
- 4. Replacement requires mechanical skill.
- 5. DCT model only
- 6. Except DCT model

^{**} In the interest of safety, we recommend these items be serviced only by a dealer.