
Описание тестового стенда Wi-Fi

1. Общая схема тестового стенда



В тестовом стенде организованы два VLAN:

- VLAN 10 для передачи трафика управления между контроллером и точками доступа;
- VLAN 20 для передачи пользовательского трафика.

Каждая точка доступа Wi-Fi управляется через VLAN 10, а через VLAN 20 передает трафик пользователей в сеть. Раздачей IP-адресов точкам доступа и пользователям сети занимается DHCP-сервер на контроллере. Сам же контроллер выступает в роли маршрутизатора между сетями VLAN 10, VLAN 20 и НОЦ. Все пакеты, маршрутизируемые контроллером в сеть НОЦ (через интерфейс enp0s3), подвергаются NAT.

Аутентификация пользователей сетей Wi-Fi производится централизованно через web-портал.

2. План IP-адресации

ІР-адрес	VLAN	Назначение
Подсеть 172.16.10.0	/24	

172.16.10.1	10	Адрес интерфейса enp0s8.10 контроллера	
172.16.10.2	10	Адрес коммутатора SW1 в сети VLAN 10	
172.16.10.3	10	Адрес коммутатора SW2 в сети VLAN 10	
172.16.10.4 - 49	10	Зарезервированные ІР-адреса	
172.16.10.50 - 254	10	Адреса для динамической выдачи	
Подсеть 172.16.20.0 /24			
172.16.20.1	20	Адрес интерфейса enp0s8.20 контроллера	
172.16.20.2	20	Адрес коммутатора SW1 в сети VLAN 20	
172.16.20.3	20	Адрес коммутатора SW2 в сети VLAN 20	
172.16.20.4 - 9	20	Зарезервированные ІР-адреса	
172.16.20.10 - 254	20	Адреса для динамической выдачи	
Подсеть 172.16.0.0 /24			
172.16.0.245	1	Адрес интерфейса enp0s3 контроллера	

3. Настройка контроллера SoftWLC

3.1 Настройка сетевых интерфейсов контроллера

source /etc/network/interfaces.d/*

The loopback network interface auto lo iface lo inet loopback

auto enp0s3 iface enp0s3 inet static address 172.16.0.245 netmask 255.255.255.0 gateway 172.16.0.1 dns-nameservers 8.8.8.8 8.8.8.4 pre-up iptables-restore < /etc/iptables.rules

auto enp0s8.10 iface enp0s8.10 inet static address 172.16.10.1 netmask 255.255.255.0 vlan_raw_device enp0s8

auto enp0s8.20 iface enp0s8.20 inet static

```
address 172.16.20.1
netmask 255.255.255.0
vlan_raw_device enp0s8
```

```
3.2 Настройка маршрутизации и NAT.
     Включение опции ip_forwarding в файле /etc/sysctl.conf:
                            net.ipv4.ip_forward=1
     Настройка правил NAT в файле /etc/iptables.rules:
     # Generated by iptables-save v1.6.0 on Mon Apr 15 15:28:03 2019
     *nat
     :PREROUTING ACCEPT [14864:1665610]
     :INPUT ACCEPT [8411:1115449]
     :OUTPUT ACCEPT [12215:1010160]
     :POSTROUTING ACCEPT [11600:964671]
     -A POSTROUTING -o enp0s3 -j MASQUERADE
     COMMIT
     # Completed on Mon Apr 15 15:28:03 2019
     # Generated by iptables-save v1.6.0 on Mon Apr 15 15:28:03 2019
     *filter
     :INPUT ACCEPT [285:36362]
     :FORWARD ACCEPT [0:0]
     :OUTPUT ACCEPT [275:37614]
     -A FORWARD -m conntrack --ctstate RELATED,ESTABLISHED -j
ACCEPT
     COMMIT
     # Completed on Mon Apr 15 15:28:03 2019
     3.3 Конфигурация DHCP-сервера контроллера.
     Прослушиваемые интерфейсы виртуальной машины:
                     INTERFACES="enp0s8.10 enp0s8.20"
     Конфигурация пулов DHCP-сервера:
     default-lease-time 600;
     max-lease-time 7200;
     log-facility local7;
     subnet 172.16.10.0 netmask 255.255.255.0 {
      range 172.16.10.50 172.16.10.254;
      option routers 172.16.10.1;
      option domain-name-servers 8.8.8.8, 8.8.8.4;
```


subnet 172.16.20.0 netmask 255.255.255.0 {


range 172.16.20.10 172.16.20.254;

```
option routers 172.16.20.1;
option domain-name-servers 8.8.8.8, 8.8.8.4;
```


4. Настройка сетей Wi-Fi


4.1. Настройка сети Koridor







4.2. Настройка сети NOC404





4.3. Настройка сети IronDoor





5. Конфигурации коммутаторов

5.1. Конфигурация коммутатора SW1

```
vlan 10,20
exit
!
interface gigabitethernet 1/0/3
switchport mode trunk
switchport trunk allowed vlan add 10,20
exit
!
interface gigabitethernet 1/0/4
switchport mode trunk
switchport mode trunk
switchport trunk allowed vlan add 10,20
exit
!
interface vlan 10
ip address 172.16.10.2 255.255.255.0
exit
!
interface vlan 20
```

5.2. Конфигурация коммутатора SW2

```
vlan database
vlan 10,20
exit
interface gigabitethernet 1/0/1
switchport mode general
switchport general allowed vlan add 20 tagged
switchport general allowed vlan add 10 untagged
switchport general pvid 10
exit
interface gigabitethernet 1/0/2
switchport mode general
switchport general allowed vlan add 20 tagged
switchport general allowed vlan add 10 untagged
switchport general pvid 10
exit
interface gigabitethernet 1/0/6
switchport mode trunk
switchport trunk allowed vlan add 10,20
exit
interface gigabitethernet 1/0/7
switchport mode general
switchport general allowed vlan add 20 tagged
switchport general allowed vlan add 10 untagged
switchport general pvid 10
exit
interface vlan 10
ip address 172.16.10.3 255.255.255.0
exit
interface vlan 20
ip address 172.16.20.3 255.255.255.0
exit
```