Instructions for use: NeuroStat Fathom

NeuroStat Fathom

Read all of this document carefully before you start. Keep it: you may need to read it again. If you have further questions, ask your doctor, pharmacist or occupational health service.

1. What NeuroStat Fathom is

NeuroStat Fathom is a magnetic resonance imaging system, class IIa. It is intended for: structural and functional imaging of the adult brain, including research on sleep, memory and attention.

How it works

Fathom is a head-only MRI scanner with a 7 tesla magnet. The superconducting coil is immersed in a sealed bath of liquid helium that holds about 14 litres, where a whole-body scanner holds well over a thousand. Because the helium stays sealed in, there is no quench pipe, and the scanner fits in a standard 3 tesla room. The patient lies on a couch and slides in head first. A structural scan takes about half as long as at 3 tesla for the same resolution.

2. Before you use it

- Fathom is operated by trained radiographers under the supervision of a radiologist or neurologist.
- Every implant must be checked against the 7 tesla device list before the scan. If an implant is not on the list, the patient is not scanned.
- Some patients feel dizzy, taste metal or see flashes of light as they move in and out of the magnet. This passes within minutes.
- Everyone in the room wears hearing protection during a scan.

3. Reporting problems

If you notice any side effect or problem, talk to your doctor, pharmacist or occupational health service. You can also report it to your national authority and to NeuroStat at safety@neurostat.com. Reporting helps provide more information on the safety of this product.

4. About this document

Manufacturer: NeuroStat Diagnostics AG, Basel, a company of the NeuroStat group. Marketing responsibility: NeuroStat Holding AG, Thurgauerstrasse 66, 8050 Zürich, Switzerland. Launched 2027. Last revised September 2028.