Manuals + — User Manuals Simplified.



August 26, 2022 Leave a comment

Home » Nokia » NOKIA N139DL Flip Phone User Guide



Quick Start Guide

Nokia xx

Contents [hide]

- 1 Included in this package:
- 2 Initial Phone Setup:
- 3 Security Settings:
- 4 Lock and unlock your phone:
- 5 Bluetooth® Connectivity:
- 6 Notification and Status Icons:
- 7 Documents / Resources
- 8 Related Posts

Included in this package:

- Activation Card
- Quick Start Guide
- About Your Phone booklet
- Phone
- Battery
- Battery Cover

• Charger

Your phone already has a SIM card installed. Your phone's battery may not be fully charged. Use the charger included in your package to charge your phone fully before the first use. To turn your phone ON/OFF, press and hold the Power/End key.

Explore your phone:

To open the apps list, press the center key. To open an app or select a feature, scroll to the app or feature and select SELECT.

To go back to the previous view, press the back key. To go back to the home screen, press the Power/End key.

Security Settings:

- 1. Press the center key and select Settings.
- 2. Scroll right to Privacy & Security.
- 3. Select Screen Lock > Screen Lockand > On, create a four-digit code. Note, however, that you need to remember the code you created, as Tracfone is not able to open or bypass it.

Lock and unlock your phone:

If you want to avoid accidentally making a call when your phone is in your pocket or bag, you can lock your keys and screen.

To lock your keys and screen, press and hold the

* key or close the fold. To unlock the keys and screen, select Unlock.

Make and Receive Calls:

- 1. Type in the phone number.
- 2. Press the Call key.
- 3. To end the call, press the Power/End key.
 When the phone rings, press the Call key to answer. To reject a call, press the Power/End key.

Voicemail Setup:

For instructions on how to set up voicemail, contact your service provider.

When you have new voice mail appears in the status bar. Swipe down and tap the notification to listen to the voicemail.

Text and Picture Messaging:

- 1. Press the center key, and select Messages > New.
- 2. In the To field, press # until you are able to enter numbers and then type in

- 4. To add a picture to the message, select Options > Add attachment.
- 5. Select the location of the picture, then the picture, and select Done.
- 6. Select SEND.

Turn on Wi-Fi:

- 1. Press the center key and select Settings > Network & Connectivity > Wi-Fi.
- 2. Turn Wi-Fi to On.
- 3. Select Available networks and the network you want, enter a password if needed, and select Connect.

Using your Mobile Internet:

- 1. Press the center key, and select Internet.
- 2. Select Search Internet.
- 3. Write a web address, and select GO.
- 4. Use the center key to move the mouse cursorin the browser.

Bluetooth® Connectivity:

- 1. Press the center key, and select Settings > Network & Connectivity > Bluetooth.
- 2. Turn Bluetooth to On.

Notification and Status Icons:

Bluetooth connection is on
Wi-Fi is on
Airplane mode is on
Battery status

Regulatory Agency Information		
FCC ID	2AJOTTA-1451	
Max. SAR (W/kg) – Head	0.72 W/kg	
Max. SAR (W/kg) – Body	1.32 W/kg	
HAC (Hearing Aid Compatible) & Rating	M4/T4	

tablets. Nokia is a registered trademark of Nokia Corporation. The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by HMD Global is under license.

N139DL

BC

Documents / Resources

NOKIA N139DL Flip Phone [pdf] User Guide
TA-1451, TA1451, 2AJOTTA-1451, 2AJOTTA1451, N139
DL, Flip Phone, N139DL Flip Phone, Phone

Related Posts

Nokia 3V Android Phone User Manual

Nokia 3V Android Phone User Manual -Optimized PDF Nokia 3V Android Phone User Manual - Original PDF

Xiaomi Phone Generic User Guide - Download [optimized] Xiaomi Phone Generic User Guide -Download

alcatel Smart Phone User Guide

QUICKSTART GUIDE PLEASE CONSIDER
THE ENVIRONMENT BEFORE PRINTING
www.alcatelmobile.com SNELSTARTGIDS Power

key Back Home Recent apps CJB2FE201AAA Printed...

Nokia 2.4 Mobile Phone User Manual

Nokia 2.4 Mobile Phone User Manual - Optimized PDF Nokia 2.4 Mobile Phone User Manual -Original PDF

- August 26, 2022 Nokia
- 2AJOTTA-1451, 2AJOTTA1451, FLIP Phone, N139DL, N139DL Flip Phone, Nokia, phone, TA-1451, TA1451

Next Post—

Website

NOKIA TA-1451 Flip Mobile Phone Instructions

Your email address will not be published. Required fields are marked *

Leave a comment

Comment *	
Name	
Email	

Post Comment

Search

Search ...

Search

Manuals+,home privacy

12 of 12