

Home of RF and Wireless Vendors and Resources

One Stop For Your RF and Wireless Need

EMI vs EMC

As we know EMI stands for Electromagnetic Interference and EMC stands for Electromagnetic compatibility. Both have become very vital for product development companies across the world. Electronic products and equipments developed by companies should meet EMI/EMC limits finalized by standard bodies before the products are actually launched to the market for the user. If proper guidelines are followed by manufacturers at design stage then the product will pass the EMI/EMC tests at the initial trial


RF WIRELESS TUTORIALS

```
5G NR |
Zigbee |
z-wave |
Bluetooth |
GSM | UMTS |
LTE | WLAN |
802.11ac | IoT
```

itself.Some manufacturers use emi/emc compliant components in the design that helps a lot.

If the same is not considered initially, than lot of rework need to be carried out at later stage to meet the EMI/EMC specification tests. Following are the basic difference between EMI and EMC. The designer need to consider specific industrial or military standards for the product under development.

As mentioned for any manufactured device EMI and EMC levels need to be verified. For this EMI and EMC testing is very much essential.



The figure depicts EMI and EMC.

EMI(ElectroMagnetic

| RADAR |
satellite |
Waveguide |

POPULAR TUTORIALS

DECT | ISDN | ATM | WBAN | TransferJet | BLE | Femtocell | HSPA | BACnet | Ethernet | TETRA | Underwater wireless | 5G I LiFi | LoRa | Infrared | NFC | RF measurements | VSAT | Diode | SS7 |

Interference)

Each device radiates some EM waves, which causes problem for another nearby RF/wireless system. This is called EMI. This EMI level radiated by device should be within limit so that nearby systems function properly.

EMC(Electromagnetic Compatibility)

Each device generates electric noise which passes through cables/wires and cause problem for another device connected with the same electric system. This conducted emissions(transients/ripples) should be within limit for proper functioning of the another device/system. This is called as EMC level.

References

For more on EMI and EMC basics, refer our page on EMI EMC>> .

What is Difference between

between SC-FDMA and OFDM Difference between SISO and MIMO Difference between TDD and FDD Difference between 802.11 standards viz.11-

Networking |
Network
Security |
FTTH | KNX |
WAP | Mobile
IP | Optical
Wireless |

POPULAR TERMS

Terminology
Index | WiDi vs
WiFi | RF
Components |
Optical
Components |
GSM channels |
LTE channels |
CSMA-CD/CA |
LAN vs PAN |
NFC Tag vs

Reader | VDSL vs G.fast |

Sensors |

a,11-b,11-g and 11-n OFDM vs OFDMA CDMA vs GSM

RF and Wireless Terminologies

SATELLITE RF Antenna Avionics
Wireless LiFi vs WiFi MiFi vs WiFi BPSK vs

QPSK BJT vs FET PDH vs SDH CS vs PS

MS vs PS

wireless PHY |
Diac vs Triac |
JUGFET vs

MOSFET | IoT
Wireless | RF
Over Fiber | IP2
vs IP3 | ASK
FSK PSK

Translate this page

ARTICLES T & M section

TERMINOLOGIES Tutorials Jobs & Careers

VENDORS IoT Online calculators source

codes APP. NOTES T & M World Website

HOME VENDORS T&M BOOKS

ARTICLES SOURCE CALCULATORS DOWNLOADS

TUTORIALS TERMINOLOGY NEWS CONTACT

APP.NOTES ACADEMIC GENERAL SITEMAP

©RF Wireless World 2012, RF & Wireless Vendors and Resources, Free HTML5

Templates