

ibm3033_diagnostic_sop_v.json

```
{
  "id": "SOP-IBM3033-001",
  "title": "IBM 3033: Machine Check and Functional Diagnostic Triage",
  "system": "IBM 3033",
  "component": "Processor Complex / Storage",
  "author": "SymbioStreams Semantic Bridge",
  "source": "IBM 3033 Functional Characteristics (GA22-7060)",
  "steps": [
    {
      "step": 1,
      "action": "Machine Check Analysis",
      "details": "When a Machine Check occurs, retrieve the MCIC (Machine Check Interruption Code) from real storage locations 232-239.",
      "indicator": "Bit 0 indicates System Damage. Bit 1 indicates Instruction Processing Damage."
    },
    {
      "step": 2,
      "action": "Diagnostic suite execution",
      "details": "Initiate Console Microdiagnostic Tests, Processor Functional Tests, and Storage Functional Tests.",
      "logic": "Use the diagnostic output to isolate the failing MST-80 logic card."
    }
  ]
}
```