

- 210D small check nylon ripstop

**TIMBER
RIDGE®**

screenprint logo

- webbing is sewn into seams

- stretch mesh folded over elastic binding and stitched
- should not see elastic webbing
- use elastic thread or zigzag stitch

- compression strap

- stretch mesh should sit taut against bag



- air mesh wraps around to front

**TIMBER
RIDGE®**

woven label

- "S" shaped shoulder straps

- all color matched hardware

- full diamond air mesh back panel



- add sleeve for reservoir behind laptop sleeve

- padded laptop sleeve



TIMBER RIDGE®

- woven label

- zippered mesh pocket in underside of hood