



SDF04NK7X/SDF08NK8X/SDF20NK9X Driver

Position control mode wiring diagram (24V single-ended input signal)

parameter settings	
parameter number	parameter value
PN1	Motor ID
PN4	0
PN72	1
PN111	2



Connection diagram of brake motor and servo driver