

DSP

Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Discrete Time FIR Filtering

Maxx Seminario

University of Nebraska-Lincoln

Fall 2025

Introduction: FIR Filters in Digital Signal Processing

DSP

Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

What are FIR Filters?

- **Finite Impulse Response (FIR):** Filter output depends only on current and past inputs
- Impulse response has *finite* duration (eventually becomes zero)
- Fundamental building block in discrete-time signal processing

General Form:

$$y[n] = \sum_{k=0}^M b_k x[n - k] = b_0 x[n] + b_1 x[n - 1] + \cdots + b_M x[n - M]$$

where $h[n] = b_n$ for $0 \leq n \leq M$ (impulse response coefficients)

Key Advantages:

- **Always stable** (finite sum cannot diverge)
- **Exact linear phase possible** (symmetric delay, no distortion)
- **Simple structure** (no feedback, easy to implement)

Discrete-Time Implementation of FIR Filters


DSP

Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types



Difference Equation:

$$y[n] = \sum_{k=0}^M h[k] x[n - k]$$

Computational Cost (per output sample):

- **Multiplications:** $M + 1$
- **Additions:** M
- **Memory:** M delay elements + $(M + 1)$ coefficients

Four Types of Linear-Phase FIR Filters

DSP

Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Classification by Symmetry and Length:

Type	Length	Symmetry	Applications
I	$(M + 1)$ odd M even	Symmetric $h[n] = h[M - n]$	Lowpass, highpass, bandpass Most versatile
II	$(M + 1)$ even M odd	Symmetric $h[n] = h[M - n]$	Lowpass, bandpass NOT for highpass
III	$(M + 1)$ odd M even	Antisymmetric $h[n] = -h[M - n]$	Differentiators Hilbert transformers
IV	$(M + 1)$ even M odd	Antisymmetric $h[n] = -h[M - n]$	Differentiators Hilbert transformers

Key Distinction:

- **Symmetric** (Types I & II): Real-valued frequency response
- **Antisymmetric** (Types III & IV): Imaginary frequency response

Type I: Symmetric, Odd Length

DSP


Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Impulse Response Example ($M = 8$, length = 9):



Frequency Response:

$$H(e^{j\omega}) = e^{-j\omega M/2} \underbrace{\left[h[M/2] + 2 \sum_{n=1}^{M/2} h[M/2 - n] \cos(\omega n) \right]}_{\text{Real amplitude } A_e(e^{j\omega})}$$

Type II: Symmetric, Even Length

DSP


Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Impulse Response Example ($M = 7$, length = 8):



Frequency Response:

$$H(e^{j\omega}) = e^{-j\omega M/2} \cos(\omega/2) \underbrace{P(\cos \omega)}_{\text{Polynomial}}$$

Limitation: $\cos(\pi/2) = 0$ forces $H(e^{j\pi}) = 0$ (cannot realize highpass)

Efficient Implementation: Exploiting Symmetry

DSP

Maxx Seminario


Introduction

Implementation

Linear Phase FIR
Filter Types

For Symmetric FIR Filters (Types I & II):

Since $h[n] = h[M - n]$, we can reduce computations by 50%



Optimized Cost: Trading Multiples for Additions

- **Multiplications:** $\lceil (M + 1)/2 \rceil$ (50% reduction!)
- **Additions:** M (pre-additions) + $\lceil (M + 1)/2 \rceil - 1$ (post-additions)
- **Memory:** Still M delays + $(M + 1)$ coefficients

Type III: Antisymmetric, Odd Length

DSP


Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Impulse Response Example ($M = 8$, length = 9):



Frequency Response:

$$H(e^{j\omega}) = j e^{-j\omega M/2} \sin(\omega) P(\cos \omega)$$

Limitation: $\sin(0) = 0$ forces $H(e^{j\pi 0}) = 0$ (cannot realize lowpass)

Type IV: Antisymmetric, Even Length

DSP


Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Impulse Response Example ($M = 7$, length = 8):



Frequency Response:

$$H(e^{j\omega}) = j e^{-j\omega M/2} \sin(\omega/2) P(\cos \omega)$$

Limitation: $\sin(0) = 0$ forces $H(e^{j\pi(0)}) = 0$ (cannot realize lowpass)

Comparison: All Four Types

DSP

Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Property	Type I	Type II	Type III	Type IV
M	Even	Odd	Even	Odd
Length ($M + 1$)	Odd	Even	Odd	Even
Symmetry	Sym	Sym	Antisym	Antisym
$h[M/2]$	Non-zero	N/A	Zero	N/A
$H(0)$	Any	Any	Zero	Non-zero
$H(\pi)$	Any	Zero	Zero	Non-zero
Lowpass	✓	✓	✗	✗
Highpass	✓	✗	✗	✓
Bandpass	✓	✓	✗	✓
Differentiator	✗	✗	✓	✓
Hilbert	✗	✗	✓	✓

Design Choice:

- Type I: Most versatile, use for general frequency-selective filters
- Type II: Lowpass only (response forced to zero at $\omega = \pi$)
- Types III & IV: Specialized applications (differentiators, Hilbert)

Frequency Response Constraints

DSP




Maxx Seminario

Introduction


Implementation

Linear Phase FIR
Filter Types

Why certain applications are prohibited:



Type III



Type IV

FIR vs IIR Filters: Implementation Comparison

DSP

Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Property	FIR Filters	IIR Filters
Stability	Always stable (no feedback)	Can be unstable (pole locations critical)
Phase Response	Exact linear phase possible (Types I-IV)	Nonlinear phase (except Bessel approximation)
Filter Order	Higher order needed (typically 10-100+ taps)	Lower order (typically 2-10 poles)
Computation	More operations per sample ($M + 1$ multiplies)	Fewer operations (typically < 10 multiplies)
Memory	More memory (M delays)	Less memory (order of filter)
Finite Wordlength	Robust (no limit cycles, low sensitivity)	Sensitive (limit cycles, pole location errors)
Design	Systematic (windowing, Parks-McClellan)	More complex (bilinear transform, pole placement)

When to Use FIR vs IIR Filters

DSP

Maxx Seminario

Introduction

Implementation

Linear Phase FIR
Filter Types

Choose FIR When:

- **Linear phase required**

- Audio processing
- Image processing
- Data transmission

- **Stability critical**

- Safety systems
- Embedded systems

- **Fixed-point implementation**

- Low wordlength DSPs
- Quantization robustness needed

Choose IIR When:

- **Computational efficiency critical**

- Real-time constraints
- Low-power devices
- High sample rates

- **Sharp transitions needed**

- Narrow stopband
- Steep rolloff
- Lower order achievable

- **Memory limited**

- Small coefficient storage
- Few delay elements

General rule of thumb:

- Use **FIR** for audio/video (linear phase) and when stability/robustness are critical
- Use **IIR** for control systems and when computational resources are constrained