

Introduction to Semiconductor Physics

Crystal Structure, Energy Bands, and Doping

Maxx Seminario

University of Nebraska-Lincoln

Spring 2026

Why Study Semiconductors?

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic
Semiconductors

Doped
Semiconductors

Current Flow in
Semiconductors

Summary

Foundation of Modern Electronics:

- Diodes, transistors, and integrated circuits
- Between conductors and insulators
- Controllable electrical properties

Key Questions:

- What makes silicon special?
- How do electrons move in semiconductors?
- What are energy bands?
- How does doping change conductivity?

Applications:

- Microprocessors and memory
- Sensors and photodetectors
- Power electronics
- RF and communication devices

Lecture Objectives

- Understand crystal structure
- Learn about energy bands
- Explore intrinsic vs extrinsic semiconductors
- Understand n-type and p-type doping

Types of Materials by Conductivity

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic
Semiconductors

Doped
Semiconductors

Current Flow in
Semiconductors

Summary

Material	Resistivity ($\Omega \cdot \text{m}$)	Band Gap (eV)	Examples
Conductors	10^{-8} to 10^{-6}	0	Copper, Aluminum, Gold
Semiconductors	10^{-5} to 10^3	0.5 to 3	Silicon, Germanium, GaAs
Insulators	10^{11} to 10^{16}	> 5	Glass, Rubber, Diamond

- **Conductors:** Many free electrons, low resistance
- **Insulators:** Almost no free electrons, very high resistance
- **Semiconductors:** Few free electrons at room temperature, but controllable ('magic rocks')

Silicon Crystal Structure

Semiconductor Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic Semiconductors

Doped Semiconductors

Current Flow in Semiconductors


Summary

Silicon Atom:

- Atomic number: 14
- 4 valence electrons
- Forms covalent bonds

Diamond Lattice:

- Face-centered cubic structure
- Each Si atom bonds with 4 neighbors
- Tetrahedral arrangement
- Very stable at room temperature



Covalent Bonding: Each bond shares 2 electrons

2D Representation of Silicon Lattice

Semiconductor Physics

Maxx Seminario

Introduction

Crystal Structure


Energy Bands

Intrinsic Semiconductors

Doped Semiconductors

Current Flow in Semiconductors

Summary



Perfect crystal at 0 K: all electrons in bonds

- At absolute zero (0 K): all valence electrons are bound in covalent bonds
- No free electrons \Rightarrow acts as an insulator at 0 K
- At room temperature: thermal energy breaks some bonds

Energy Levels in Atoms vs. Crystals

Semiconductor Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic Semiconductors

Doped Semiconductors

Current Flow in Semiconductors


Summary

Isolated Silicon Atom:

- Discrete energy levels
- 4 valence electrons
- Well-defined orbital energies

Silicon Crystal:

- $\sim 10^{22}$ atoms/cm³
- Energy levels merge into bands
- Continuous range of energies



Energy Band Diagram

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure


Energy Bands

Intrinsic
Semiconductors

Doped
Semiconductors

Current Flow in
Semiconductors

Summary



- **Valence Band:** Energy levels of bonded electrons
- **Conduction Band:** Energy levels of free electrons
- **Band Gap (E_g):** Energy needed to free an electron from a bond
- For silicon: $E_g = 1.12 \text{ eV}$ at room temperature

Conductors, Semiconductors, and Insulators

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure


Energy Bands

Intrinsic
Semiconductors

Doped
Semiconductors

Current Flow in
Semiconductors

Summary



- **Conductors:** Bands overlap, electrons flow easily
- **Semiconductors:** Small band gap, thermally activated conduction
- **Insulators:** Large band gap, very few free electrons

Electron-Hole Pair Generation

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic
Semiconductors

Doped
Semiconductors

Current Flow in
Semiconductors

Summary


Thermal Excitation:

- At $T > 0$ K, thermal energy breaks bonds
- Electron 'jumps' from valence band to conduction band
- Leaves behind a **hole** in valence band
- Creates electron-hole pair

Intrinsic Carrier Concentration

$$n_i = p_i \approx 1.5 \times 10^{10} \text{ cm}^{-3}$$

at 300 K for silicon



Holes: Positive Charge Carriers

Semiconductor Physics

Maxx Seminario

Introduction

能帶

Intrinsic
Semiconductors

Doped
Semiconductors

電流傳導
在半導體

Summary

What is a Hole?


- Absence of electron in covalent bond
- Acts like positive charge carrier
- Can move through crystal
- Real concept, not just theoretical

Hole Motion:

- Adjacent electron fills the hole
- Creates new hole at previous location
- Hole appears to move opposite to electrons

Charge and Current

- **Electron:** charge = $-q$, moves toward +
- **Hole:** charge = $+q$, moves toward -



Both contribute to current in same direction!

Intrinsic Semiconductor Properties

Semiconductor Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic Semiconductors


Doped Semiconductors

Current Flow in Semiconductors

Summary

Pure (Intrinsic) Semiconductor:

- No impurities added
- Equal number of electrons and holes: $n = p = n_i$
- Low conductivity at room temperature



Mass Action Law

$$n \cdot p = n_i^2$$

Valid for both intrinsic and doped semiconductors at thermal equilibrium

Why Doping?

Problem with Pure Silicon:

- Very low conductivity
- $n_i \approx 10^{10} \text{ cm}^{-3}$
- Compare to Si atoms: $\approx 5 \times 10^{22} \text{ cm}^{-3}$
- Only 1 in 10^{12} atoms contributes a charge carrier (electrical current)

Solution: Doping

- Add impurity atoms
- Controlled introduction
- Typical: 1 dopant per 10^6 to 10^8 Si atoms
- Increases electrical conductivity

Types of Doping

- **n-type:** Add donors (extra electrons)
- **p-type:** Add acceptors (create holes)

Dopant	Type
Phosphorus (P)	n-type
Arsenic (As)	n-type
Antimony (Sb)	n-type
Boron (B)	p-type
Aluminum (Al)	p-type
Gallium (Ga)	p-type

n-Type Semiconductor (Donor Doping)

Semiconductor Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic Semiconductors

Doped Semiconductors

Current Flow in Semiconductors


Summary

Adding Phosphorus (P):

- P has 5 valence electrons
- Si has 4 valence electrons
- P substitutes for Si in lattice
- 4 electrons form bonds
- 5th electron is loosely bound
- Easily freed to conduction band

n-Type Properties

- $n \gg p$ (electrons dominate)
- Electrons = majority carriers
- Holes = minority carriers
- $n \approx N_D$ (dopant concentration)



Donor atom donates electron

p-Type Semiconductor (Acceptor Doping)

Semiconductor Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic Semiconductors

Doped Semiconductors

Current Flow in Semiconductors


Summary

Adding Boron (B):

- B has 3 valence electrons
- Si has 4 valence electrons
- B substitutes for Si in lattice
- Only 3 electrons available for 4 bonds
- Creates a hole (missing electron)
- Accepts electron from neighboring bond

p-Type Properties


- $p \gg n$ (holes dominate)
- Holes = majority carriers
- Electrons = minority carriers
- $p \approx N_A$ (dopant concentration)



Acceptor atom accepts electron (creates hole)


Energy Band Diagram: Doped Semiconductors

n-Type:



$$n \gg p$$

p-Type:



$$p \gg n$$

- Donor level near E_c
- Easy to ionize donors
- Many electrons in CB

- Acceptor level near E_v
- Easy to ionize acceptors
- Many holes in VB

Two Mechanisms of Current Flow

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic
Semiconductors

Doped
Semiconductors

Current Flow in
Semiconductors

Summary

1. Drift Current:

- Caused by electric field
- Electrons drift opposite to field, holes drift with field
- $J_{drift} = q(n\mu_n + p\mu_p)E$
- μ_n, μ_p are electron and hole mobilities

2. Diffusion Current:

- Caused by concentration gradient
- Carriers move from high to low concentration
- $J_{diff,n} = qD_n \frac{dn}{dx}, \quad J_{diff,p} = -qD_p \frac{dp}{dx}$
- D_n, D_p are diffusion constants

Total Current

$$J_{total} = J_{drift} + J_{diffusion}$$

Both mechanisms important in semiconductor devices (especially pn junctions)

Conductivity of Doped Semiconductors

Conductivity Formula:

$$\sigma = q(n\mu_n + p\mu_p)$$

n-Type:

- $n \approx N_D$ (donor concentration)
- $p \ll n$ (minority carriers)
- $\sigma \approx qN_D\mu_n$
- Conductivity dominated by electrons

Example: $N_D = 10^{16} \text{ cm}^{-3}$

- 1,000,000 times more carriers than the intrinsic semiconductor
- Much higher conductivity

p-Type:

- $p \approx N_A$ (acceptor concentration)
- $n \ll p$ (minority carriers)
- $\sigma \approx qN_A\mu_p$
- Conductivity dominated by holes

Mass Action Law still holds:

$$n \cdot p = n_i^2$$

$$\text{For n-type: } p = \frac{n_i^2}{N_D^2}$$

$$\text{For p-type: } n = \frac{n_i^2}{N_A}$$

Typical Doping Concentrations

Type	Concentration (cm^{-3})	Application
Intrinsic Si	$n_i = 1.5 \times 10^{10}$	Reference
Lightly doped	$10^{14} - 10^{16}$	Base regions, substrates
Moderately doped	$10^{16} - 10^{18}$	Emitter, collector regions
Heavily doped	$10^{18} - 10^{20}$	Contacts, low-resistance paths

- Silicon has $\approx 5 \times 10^{22}$ atoms/ cm^3
- Even "heavy" doping is only ≈ 1 dopant per 1000 Si atoms
- Precise control needed for device fabrication
- Ion implantation and diffusion are common doping techniques

Key Formulas Reference

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic
Semiconductors

Doped
Semiconductors

Current Flow in
Semiconductors

Summary

Parameter	Formula
Intrinsic carrier conc.	$n_i \approx 1.5 \times 10^{10} \text{ cm}^{-3}$
Mass action law	$n \cdot p = n_i^2$
n-type majority	$n \approx N_D$
n-type minority	$p \approx \frac{n_i^2}{N_D}$

Parameter	Formula
p-type majority	$p \approx N_A$
p-type minority	$n \approx \frac{n_i^2}{N_A}$
Conductivity	$\sigma = q(n\mu_n + p\mu_p)$
Drift current density	$J = \sigma E$

Summary: Semiconductor Fundamentals

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic
Semiconductors

Doped
Semiconductors

Current Flow in
Semiconductors

Summary

1 Crystal Structure:

- Silicon forms diamond lattice with covalent bonds
- 4 valence electrons per atom

2 Energy Bands:

- Valence band (bonded electrons) and conduction band (free electrons)
- Band gap $E_g = 1.12 \text{ eV}$ for silicon
- Thermal energy creates electron-hole pairs

3 Doping:

- n-type: donor atoms (P, As) provide extra electrons
- p-type: acceptor atoms (B, Al) create holes
- Dramatically increases conductivity

4 Current Mechanisms:

- Drift (electric field) and diffusion (concentration gradient)
- Both important in devices

Next Lecture: The pn Junction

Semiconductor
Physics

Maxx Seminario

Introduction

Crystal Structure

Energy Bands

Intrinsic
Semiconductors


Doped
Semiconductors

Current Flow in
Semiconductors

Summary

Coming Up:

- What happens when p-type and n-type meet?
- Depletion region formation
- Built-in potential
- Forward and reverse bias
- V-I characteristics of diodes
- Diode circuit applications



Prepare: Review band diagrams and carrier concentrations