


VESTA RV32IMAC Core



Key: ■ Control ■ Datapath ■ Interrupt ■ CSR ■ Memory ↔ Data Bus → Control