## Lecture 11

Monday, September 28, 2015 9:59 AM


## 6502


- · First real CPU, unlike SCRAM
- Approved for pacemakers
- 1975
- 8-bit like SCRAM
- Only add and subtract
- 16-bit address bus (65536 memory locations)

## P( 1 ( 5,4

## Website Resources

- Obelisk.me.uk/6502
- http://skilldrick.github.io/easy6502/





Ibyle instruction

2 byte in syrumone, opcode, operand

I 3 byte instructions, opcode, 2 operands.

transfer 5h, f+ 1m5+ru(+,0ms

010 15 010 1 5 roughly and divide 1010 10 0010 2 by 2. fills in with 0's

rotate (what ever is shifted out, comes back)

Branches / Flags individuel bits in a Pregister [M71111] prolessor status.

Zero bit Sot and clear

Negative bit