Instalación

Hola! Esta es nuestra guía de instalación, bienvenides :)

Esta guía incluye información actualizada en junio 2021, y estaremos incluyendo explícitamente las versiones de los software que estamos usando.

Recomendamos instalar las mismas versiones que estamos usando, y si hay un problema con la biblioteca o software relacionado, por favor haznos saber por correo electrónico o el sistema de reportes del repositorio.

Para documentación adicional, por favor visita el sitio web oficial de documentación de Arduino en docs.arduino.cc,y en particular la documentación del microcontrolador Arduino Nano 33 BLE Sense en docs.arduino.cc/hardware/nano-33-ble-sense.

Arduino IDE


Descarga e instala el software Arduino IDE, disponible en https://www.arduino.cc/en/software. Selecciona el lanzamiento estable (stable release) correspondiente al sistema operativo de tu computador.

En junio 2021, estamos usando Arduino IDE 1.8.15.

Arduino Mbed OS Nano boards


Después de instalar el software Arduino IDE, necesitamos instalar bibliotecas para nuestro microcontrolador Arduino Nano 33 BLE Sense. Abre la Arduino IDE y navega en el menú al Boards Manager:

Tools > Board: "<board_name>" > Boards Manager...



Usa la barra de búsqueda para encontrar la opción Arduino Mbed OS Nano Boards e instálala, esto puede tomar un tiempo largo.

En junio 2021, estamos usando la versión 2.2.0.




Después de que la instalación está lista, podemos seleccionar el microcontrolador que vamos a utilizar (Arduino Nano 33 BLE), desde el menú Tools:

Tools > Board: "<board_name>" > Arduino Mbed OS Nano Boards > Arduino Nano 33 BLE


Por favor nota que esta opción es válida para el microcontrolador Arduino Nano 33 BLE, y para el que estamos usando, Arduino Nano 33 BLE Sense.

Bibliotecas Arduino

A continuación instalaremos todas las bibliotecas necesarias para este proyecto. En la Arduino IDE, navega en el menú a Tools > Manage Libraries... >



Usa la barra de búsqueda del Libraries Manager para encontrar TinyTrainable. Esta instalación te dará la opción de también instalar todas sus dependencias, selecciona Install all para también descargarlas.



En junio 2021, la versión 0.2.2 es la más reciente de la biblioteca TinyTrainable, y tiene estas dependencias:

- Bibliotecas para usar los sensores del microcontrolador:
 - Arduino_APDS9960: color, proximidad
 - Arduino_LSM9DS1 aceleración, campo magnético, orientación giroscopio
- Bibliotecas para aprendizaje de máquinas:
 - o Arduino_KNN: algoritmo vecino de cercanía k.
 - Arduino_TensorFlowLite: versión para microcontroladores de la biblioteca TensorFlow de aprendizaje de máquinas. Por favor descarga la versión no-precompilada más reciente.
- Bibliotecas para salida multimedia:
 - Adafruit GFX Library: para salida con pantalla.
 - Adafruit SSD1306: para salida con pantalla.
 - Adafruit Thermal Printer Library: para salida con impresora térmica.
 - Servo: para salida con motores servo.

Python for machine learning

For input-color, you only need Arduino libraries.

For input-gesture and speech, you either need to install specific Python libraries on your computer, or use the free Google Colab service, because we will create databases and train algorithms on a computer.

For beginners, we suggest using Google Colab, because it will be an easier installation, and the algorithms will run faster.

If you decide to run the algorithms on your machine, you will need Python, TensorFlow and Jupyter.

These are the versions we will be using, as of June 2021:

- Python 3.8.6
- TensorFlow 2.3.2
- Jupyter Lab 3.0.5

Your computer might have Python already installed, but it might be one that is not compatible with the TensorFlow version we are using, so we suggest using a Python version manager, like the tool pyenv https://github.com/pyenv/pyenv.

After installing pyenv, open the terminal and go to this repository. If you dont know how to download a repository to your machine, follow this tutorial about cloning repositories from GitHub.

```
cd tiny-trainable-instruments/
```

Check that pyenv is able to read the .python-version file

```
pyenv versions
```

You should see a list, with the version we are using and an asterisk, to highlight that this is the Python version we will use. If there is no asterisk and it says that the required version of Python is not installed, use the command:

```
pyenv install <python version number>
```

If you are using an old version of pyenv, there's a chance that the install won't work; copy the entire command pyenv gives you (including the &&'s) and enter it into the terminal. Then once pyenv is updated, try the above command again.

Now that you have the correct version of Python, create a virtual environment (which we will name env) using the Python package venv. Most dependency problems can be solved by using a virtualenv; we can't support issues not using a virtualenv due to the huge variety of system configurations. On your terminal type:

```
python -m venv env
```

Activate the virtual environment with this command, which you will use every time you want to enter the venv:

```
source env/bin/activate
```

Now your terminal should have every new line starting with (env). Your command prompt should look something like this:

../docs/images/1-arduino-boards-manager

```
maxwell@Maxwells-MacBook-Pro → instruments git:(main) x python -m venv env maxwell@Maxwells-MacBook-Pro → instruments git:(main) x source env/bin/activate (env) maxwell@Maxwells-MacBook-Pro → instruments git:(main) x
```

The pip of your Python virtual environment might need updating; you can update to the latest version with the command

```
pip install ——upgrade pip
```

Then use pip to install the Jupyter packages, along with their dependencies:

```
pip install -r requirements.txt
```

Now you can run the Jupyter Lab tool with jupyter-lab. This will open a tab on your browser to navigate through the files in your computer and allow you run code and read the documentation.

The code for input-gesture and input-speech is written using Jupyter notebooks, which have the extension .ipynb, and are located on the folder instruments/. The documentation is written in several Markdown files with extension .md. These files are on the folder docs/, which includes an index on README.md.

If you double click on a Markdown file, it will open an Editor window with the Markdown code. To view the rendered text you can right click and select "Open with Markdown Preview". If you have internet connection, it might be more convenient to access the online documentation on the online repository.

To close the Jupyter notebook server, press ctrl-c in the terminal (even on OSX; it's not cmd) and confirm with y.

To exit the virtual environment once you're done, use the command deactivate. Note that the command jupyter-lab will not work until you reactive the virtual environment.