MASTER·COPY

	Biomedical Limited, No 1 Ohimege Road, Industrial Estate, Ilorin Kwara State, PMB 1449		MASTER COPY STAMP HERE
Biomedical	Title: **SOP for Preparing a Batch of Intravenous Infusion**		

Department	Unit:	BML-PDF-PR-016	Revision No.:	06
			Effective Date:	April, 2025
PRODUCTION	PROCESSING		Next Review Date:	March, 2027
Prepared By: RABIU IM		Checked By: Ajibola L-A	Approved By: Kuroma A	
Sign /date: 28/04/2025		Sign /date: 28/04/25	Sign /date: 28/04/25	

1.0 OBJECTIVE:

To provide the methods required in producing a batch of intravenous fluid.

2.0 SCOPE:

To provide written guidelines for preparing a batch of intravenous infusion.

3.0 RESPONSIBILITIES/ACCOUNTABILITIES:

Production Pharmacist, Production Supervisors, Foremen, Operators.

4.0 ABBREVIATION AND DEFINITIONS

S/S= Stainless Steel.

BMR= Batch Manufacturing Record.

5.0 PROCEDURES

PRE-PRODUCTION CHECKS

- Check for the pre-production plan and ensure that the raw materials are dispensed for the batch (follow appropriate requisition procedure).
- Check that the BMR is available and that it has been appropriately stamped and authorized.
- Ensure that the AHU (air handling unit) is operational and that adequate pressure differential is maintained.
- Also ensure that the temperature and relative humidity are within the specified range (22°C-25°C and 40-60% RH respectively).

MANUFACTURING

1. Check for the batch number, manufacturing and expiry date(s) coding on the pouches in order to sign the rechecked column of the BMR.
2. Ensure the mixing tank is free from the previous product.
3. Allow QC to have a sample of the WFI from the collection loop.
4. After approval from QC, resume collecting WFI for production.
5. Check the weight of the dispensed raw materials and ensure that they are correct. Report any discrepancies to the Pharmacist in charge.
6. Check the master formulation method mentioned in the BMR and ensure that there are no modifications authorized.
7. Manufacture the batch according to the procedure given, if any.

BIOMEDICAL LTD
UNCONTROL COPY

CONTROL COPY

GOOD CLEAN PRACTICES IN MANUFACTURING

1. Ensure that the clean area garments are worn properly and that the nose, mouth and hairs are covered.
2. Wear latex hand gloves while weighing raw materials.
3. Do not touch the walls and railings of the mezzanine floor while wearing hand gloves, replace hand gloves if this occurs.
4. While adding acid or alkali for pH adjustment do so slowly and allow sufficient time to mix and stabilize.
5. Always keep the lid of the manhole of the mixing tank closed except when materials are being added.
6. Always write down the details required in the BMR immediately after the operation.
7. Any spillages of water and/or raw materials should be cleaned instantly.

Materials, Equipment, Apparatus and Reagents

- Release certificates.
- Status Labels.
- BMR.

6.0 REFERENCE AND ENCLOSURE

INHOUSE

7.0 TRAINING INVOLVEMENT

Production manager	Production pharmacist
Sectional heads	All production staff

8.0 DISTRIBUTION AND CONTROL

MASTER COPIES	DOCUMENTATION UNIT
CONTROLLED COPIES	PRODUCTION DEPARTMENT

9.0 CHANGE HISTORY

CURRENT REVISION	SUPERSEDE	REASON FOR REVIEW
00	Nil	First issue
06	05	• Change in sop format.

UNCONTROLLED COPY

BIOMEDICAL LTD

CONTROL COPY

		• Inclusion of traceability of enclosures to parent SOP

BIOMEDICAL LTD

UNCONTROL COPY

CONTROL COPY