BIOMEDICAL LIMITED ILORIN	STANDARD TESTING PROCEDURE **TITLE:** STANDARD CHEMICAL TESTING PROCEDURE FOR CHLOROQUINE SYRUP (60ml)		
DEPARTMENT:	**QUALITY**	**SECTION:**	**QUALITY CONTROL**
STP NO.:	**BML/QA/STP/FPS/003/F01**	**PAGE NO.:**	**Page 1 of 5**
STP Ref.:	**BML-QDG-QA-105**	**REF. BOOK**	**BP 2024/IN-HOUSE**
EFFECTIVE DATE:	**04/01/2024**	**REVISION NO:**	**01**
REVIEW DATE:	**04/01/2026**	**SUPERSEDE:**	**00**

S/N	TEST	DESCRIPTIONS OF PROCEDURE
1.	**pH**	1. Take sample sufficient to immerse the electrode-head, and dip the electrode in the sample. 2. Wait until the reading stabilises, then take readings.
2.	**Chloroquine Phosphate** **Label Claim:** **80mg/5ml**	**METHOD 1:** ***Sample and Standard solution***: An equivalent of 80mg of Chloroquine phosphate is dissolved in warm water to produce 200mL. Dilute 4mL of the resulting solution to 100mL with water. 4mL of this solution is further diluted to 100mL with water (64mcg/100mL). Measure the optical density of these solutions at 343nm. **% Assay of Chloroquine Phosphate** = $\frac{absorbance of sample}{absorbance of standard}$ x 100 **METHOD 2** ***Standard*** Weigh accurately 100mg of standard Chloroquine Phosphate and dissolve in approximately 20ml of Demineralized Water and make up to mark of an 100ml Volumetric flask. Take exactly 1ml of the resulting solution and make it up to 100ml of the same volumetric flask using the same solvent.

	DESIGNATION	SIGNATURE	DATE
PREPARED BY:	QUALITY CONTROL SENIOR ANALYST		
REVIEWED BY:	QUALITY CONTROL HEAD		
APPROVED BY:	QUALITY ASSURANCE MANAGER		

		Sample Transfer qualitatively an equivalent of 80mg (exactly 5ml) of the sample into a clean dry beaker and dilute with about 20ml of Demineralized Water, then make up to mark using a 100ml volumetric flask. Take accurately 1.25ml of the resulting solution and make up to mark of the same 100ml volumetric flask with the same solvent. Determine the absorbance at 343nm **% Assay of Chloroquine Phosphate** = $\frac{absorbance of sample}{absorbance of standard}$ x 100 ***REFERENCE:*** Sethi's Quantitative Analysis of Pharmaceutical Formulations. Vol. 2
3.	**Microbiological Test**	- Determination of total aerobic microbial count (TAMC) and total combined yeasts and molds count (TYMC) by the pour plate method. - Dispense 1 ml of diluted sample in the center of the Petri plate using a sterile micropipette or calibrated pipette. - Open the lid of the prepared media, flame its mouth. - Pour about 15 mL of sterilized molten media at the appropriate temperature above the sample. - Close the lid of the plate then mix the sample in the media properly by gently

swirling the plate. The plate is generally swirled in an "S" or "8" shape.

- Allow the media to completely solidify.
- Incubate the plate in an inverted position under suitable incubation conditions (Incubate the plates of Soybean Casein Digest Agar at 30°C-35°C for 3-5days for TAMC and the plates of Sabouraud Dextrose Agar at 20°C to 25°C for 5-7 days.

TEST FOR ABSENCE OF PATHOGEN

- Measure 10ml /10g of the samples, dilute 1n 90ml of nutrient broth
- Transfer 10ml into 90ml of Tryptone soya broth
- Incubate at 30-35^{0}c for 18-24hours
- Transfer 1 ml of the dilution into 100ml of MacConkey broth and incubate at 42-44°c in 18-72hours
- Subculture on MacConkey Agar or Eosin Methylene blue Agar and incubate at 30-35°c
- For negative control, proceeding same as above except without sample, streak a portion of incubated sterile MacConkey broth medium on the surface of Eosin Methylene Blue Agar.
- Incubate plates at 30 to 35° for 48 hours.

A. Result Interpretation

- Following the incubation, developed colonies are observed. Each colony will account for one viable microbial cell or one colony-forming unit.
- If all the colonies are of the same type, then we can predict that the sample contained only one type of microbial genera.
- However, if there are different genera or species producing similar types of colonies, it is required to carry out identification test.
- If the colonies are of different morphology, then we can conclude that the sample contained a mixed population.

Count the colonies and calculate CFU/mL by using the formula:

$$\text{CFU/mL} = \frac{\text{Total number of colonies obtained x dilution factor}}{\text{Volume of sample used (aliquot)}}$$

- This will give the total number of viable microbial cells present in the given sample.
- For optimum count, the number of colonies must be between 20 – 200 CFU/mL. Beyond this limit, the whole procedure must be repeated.
- If the number of the colony is less than 20, it is suggested to use the sample of lower dilution, whereas, if the total number of colonies exceeds 200, it is suggested to use the sample of higher dilution on successive repeats.

		- The result should be recorded following the Standard testing procedure SOP **BML-QDG-QA-105** - If the colonies are fused or the whole plate is covered with a single colony, then report as “too numerous to count” (TNTC) and repeat the process of taking the sample at a higher dilution.

*LAF--- Laminar Air Flow

CURRENT REVISION	SUPERSEDE	REASON FOR REVIEW
00	NIL	FIRST ISSUE
01	00	Review of the procedures Change in header and footer format

	DESIGNATION	SIGNATURE	DATE
PREPARED BY:	QUALITY CONTROL SENIOR ANALYST		
REVIEWED BY:	QUALITY CONTROL HEAD		
APPROVED BY:	QUALITY ASSURANCE MANAGER		