	Biomedical Limited, No 1 Ohimege Road, Industrial Estate, Ilorin Kwara State, PMB 1449			MASTER COPY STAMP HERE
	Title: **Standard Operating Procedure for Operating Generating Set**			
Department	**Unit:**	**BML-ENG-NG-002**	**Revision No.:**	05
			Effective Date:	**April, 2025**
ENGINEERING	ENGINEERING GENERAL		**Next Review Date:**	**March, 2027**
Prepared By:	**Checked By:**		**Approved By:**	
sign/date	**sign/date**		**sign/date**	

1.0 PURPOSE:

- To provide the instructions for the operating the generator set at BIOMEDICAL Limited

2.0 SCOPE:

- To provide written guidelines for operating the generator set at Biomedical Limited.

3.0 RESPONSIBILITY:

- It is the responsibility of any qualified personnel
- It is the responsibility of Biomedical Limited to provide PPE for the qualified employee performing the task
- It is the responsibility of contactors to provide PPE for their qualified staff
- It is the responsibility of the Engineering head to ensure that the SOP is strictly followed and that the right PPE are used

4.0 ABBREVIATION AND DEFINITIONS:

- SOP: Standard Operating Procedure
- PPE: Personal Protective Equipment
- GMP: Good Manufacturing Practices
- PHCN: Power Holding Company of Nigeria

5.0 PROCEDURE:

TO START

- Check the Water level, lubricating oil level and fuel level. Fill to normal operating levels if required.
- Clean the Generator and the machine bed. Check for leakages either oil or fuel.
- Check the battery and look out for loose wires on the battery terminals.
- Change over from PHCN supply to Generator

- Start the Generator by turning the ignition key or press the start push button to start the generator.
- To allow for lubricants to circulate in the engine, engage the Generator power supply circuit breaker to load the generator after 45-60 seconds.
- Get the generator record book to fill the necessary information on hourly basis

TO STOP

- Switch off the generator outlet circuit breaker
- After 45-60 seconds, turn the generator ignition key to off.
- Finally, disengage the main selector switch from the generator to PHCN supply.
- Record the stop time inside the generator usage log (with document number: BML-ENG-NG-002-F01)

6.0 REFERENCES AND ENCLOSURE:

- Generator Usage Logbook - BML-ENG-NG-002-F01)

7.0 TRAINING INVOLVEMENT:

All Engineering staff
All machine Operators

8.0 DISTRIBUTION AND CONTROL COPY:

- This is the various department/section where the SOP copies will be utilized.

MASTER COPY	QUALITY
CONTROLLED COPY	QUALITY, ENGINEERING, PRODUCTION

9.0 CHANGE HISTORY:

CURRENT REVISION	SUPERSEDE	REASON FOR REVIEW

00	Nil	First issue
01	00	To review
02	01	To review
03	02	To update as per NAFDAC Observation
04	03	To update
05	04	• Change in sop format. • Inclusion of traceability of enclosures to parent SOP