	Biomedical Limited, No 1 Ohimege Road, Industrial Estate, Ilorin Kwara State, PMB 1449			MASTER COPY STAMP HERE
	Title: **SOP for Daily Cleaning and Disinfection of Non-Sterile Areas**			
Department	Unit:	**BML-PDF-PR-001**	**Revision No.:**	06
			Effective Date:	**April, 2025**
PRODUCTION	PROCESSING		**Next Review Date:**	**March, 2027**
Prepared By:		**Checked By:**	**Approved By:**	
Sign /date		**Sign /date**	**Sign /date**	

1.0 OBJECTIVE:

To provide written guidelines for cleaning of non-sterile areas.

2.0 SCOPE:

This SOP covers the procedure for cleaning of non-sterile areas in the production environment.

3.0 RESPONSIBILITIES/ACCOUNTABILITIES:

House Keeping Supervisor, Quality Assurance Officer, Microbiologist.

4.0 ABBREVIATION AND DEFINITIONS

NIL

5.0 PROCEDURES

CLEANING OF THE AREA

- De-dust all the area viz. Corridors, Autoclave Floor, Production Floor, Finished goods Store, Weekly Raw Material Store, Main Raw Material Store, Pouch & Flat carton Store.
- Remove all visible particles from the walls with the aid of production area designated clean broom.
- Then sweep the floor with clean broom.
- Clean all the windows & Door glasses with glass cleaner liquid & soft mop.
- Prepare 2% v/v Soap solution & mop the area with it using clean mop-brush.
- Frequently wash the mop with clean water to remove the dirt collected in it.

DISINFECTION OF NON-STERILE AREA

- Prepare the disinfectant solution as per the schedule & of the specified concentration.
- Apply the disinfectant solution on the whole floor.
- Leave it like this for at least 5 minutes. Mop away the excess disinfectant solution from the floor after 5 minutes using clean water.

FREQUENCY OF CLEANING

- Clean the Production Floor, Autoclave area, Corridors at least three times in a shift.
- Clean the weekly Raw Material Store twice a shift.
- The Main Raw Material Store, Pouches & flat carton store is to be cleaned three times a week i.e. every alternate day.

BIOMEDICAL LTD

- The Boiler Room, Water Treatment Area is to be cleaned twice a shift.
- The generator house & Engineering Workshop is to be cleaned once in a shift.

MAINTAINING THE CLEANLINESS OF AREA

- Ensure there is no accumulation of water, oil or grease on the floor.
- Be prompt to clean any water spillage.
- Any areas if dirty clean it at once at that time only irrespective of schedule.

SCHEDULE FOR DISINFECTANTS

DAY	DISINFECTANT	CONCENTRATION	DILUTION METHOD
MON	DETTOL (Chloroxylenol Solution)	4.8%w/v	Mix 200mL with 4L of Water
TUE	PURIT (Chlorhexidine gluconate and Cetrimide Solution)	0.3% w/v + 3.0%w/v	Mix 200mL with 4L of Water
WED	DETTOL (Chloroxylenol Solution)	4.8%w/v	Mix 200mL with 4L of Water
THU	PURIT(Chlorhexidine gluconate and Cetrimide Solution)	0.3% w/v + 3.0%w/v	Mix 200mL with 4L of Water
FRI	DETTOL (Chloroxylenol Solution)	4.8%w/v	Mix 200mL with 4L of Water
SAT	Sodium Hypochlorite	6.25% v/v	Mix 200mL with 5L of Water

MATERIALS

- Clean broom
- Water Pusher
- Soap Solution
- Mop
- Disinfectant

6.0 REFERENCE AND ENCLOSURE

NIL

BIOMEDICAL LTD

7.0 TRAINING INVOLVEMENT

Production manager	Production pharmacist
Sectional heads	All production staff

8.0 DISTRIBUTION AND CONTROL:

MASTER COPIES	QUALITY ASSURANCE
CONTROLLED COPIES	ALL DEPARTMENT

9.0 CHANGE HISTORY

CURRENT REVISION	**SUPERSEDE**	**REASON FOR REVIEW**
00	Nil	First issue
06	05	• Change in sop format. • Inclusion of traceability of enclosures to parent SOP

BIOMEDICAL LTD