	Biomedical Limited, No 1 Ohimege Road, Industrial Estate, Ilorin Kwara State, PMB 1449			MASTER COPY STAMP HERE
	Title: **SOP for Cleaning and Operation of Pharma Lab Autoclave**			
Department	Unit:	**BML-PDF-PR-018**	**Revision No.:**	06
			Effective Date:	**April, 2025**
PRODUCTION	PROCESSING		**Next Review Date:**	**March, 2027**
Prepared By:		**Checked By:**	**Approved By:**	
Sign /date		**Sign /date**	**Sign /date**	

1.0 OBJECTIVE:

To provide the instructions for cleaning and operation of the Pharma Lab autoclave.

2.0 SCOPE:

To provide written guidelines for cleaning and operation of Pharma Lab Autoclave.

3.0 RESPONSIBILITIES/ACCOUNTABILITIES:

Production Pharmacist, Production Supervisors and Operators.

4.0 ABBREVIATION AND DEFINITIONS

BMR- Batch Manufacturing Record.

5.0 PROCEDURES

Cleaning Procedure:

- Ensure that all cleaning equipment are clean i.e. buckets and soft cloth.
- Make sure all reject pouches in the autoclave are removed.
- Fill all buckets needed with water sufficient quantities of liquid soap to it.
- Dip a clean napkin into the solution and clean the autoclave's interior and exterior thoroughly.
- Then use the clean fresh water to rinse the soap solution from the autoclave and make sure the solution is properly drained.
- Make sure all the exterior part of the autoclave is dried with the napkin provided then wash and dry all the cleaning equipment.
- Document the cleaning process.

NOTE:

- Do not use detergent in cleaning the autoclave.

Operation Procedure:

- Ensure that the boiler and air compressor are on, working properly and their valves open.
- Remove the 'unsterilized' tag from the trolleys.
- Wheel the loaded trolley into the autoclave and close the door.
- Switch on the main starter, Auto manual, Steam and Condensate button to start sterilization.

BIOMEDICAL LTD

- Monitor the temperature and pressure readings and record it in the autoclave log sheet book.
- When the temperature reaches 116°C; pressure, 1.5 Bar; allow to sterilize for 40 minutes; then allow the air and water cooling to complete the cooling phase.
- Once the sterilization cycle is complete, open the doors and wheel out the sterilized product from the autoclave.
- Collect the autoclave reading print out and attach to the BMR.
- Set aside quality control samples and move the sterilized product to the offloading section, sterilized product area.

Materials, Equipment, Apparatus and Reagents

- WFI water.
- Soft cloths.
- Mops.
- Buckets.
- Soap.

6.0 REFERENCE AND ENCLOSURE

User Manual, In House Method.

7.0 TRAINING INVOLVEMENT

Production manager	Production pharmacist
Sectional heads	All production staff

8.0 DISTRIBUTION AND CONTROL:

MASTER COPIES	DOCUMENTATION UNIT
CONTROLLED COPIES	PRODUCTION DEPARTMENT

BIOMEDICAL LTD

9.0 CHANGE HISTORY

CURRENT REVISION	SUPERSEDE	REASON FOR REVIEW
00	Nil	First issue
06	05	• Change in sop format. • Inclusion of traceability of enclosures to parent SOP

BIOMEDICAL LTD