
FIN FAN ACCESSORY

Adapts AutoBox ABX-2L for Fin Fan Style Exchanger Cleaning



OVERVIEW

The Fin Fan Accessory is designed to adapt the AutoBox ABX–2L and LWP-500 positioner for the specific requirements of cleaning Fin Fan style exchangers.

Fin Fan exchangers can be much wider than standard heat exchangers and are often accessed by very narrow walkways. Fin Fan Accessory components allow the ABX-2L to be safely positioned in tight walkway spaces for this type of cleaning. Customizable rail lengths and simple mounting clamps enable the positioning system to accommodate most all Fin Fan headers and configurations.


FEATURES	BENEFITS
Light weight positioning system	Easy setup and assembly in tight locationsCustomizable to fit most fin fan exchangers
Hose snout and tube guide assembly	 Accurate lance control and indexing Built-in backout prevention increases safety Adjustable pitch
Scaffold mount	Simple mounting of ABX-2L system on existing structures

SPECIFICATIONS				
Horizontal Positioner*	Full Length: 15 ft 457 cm Allowance: 30 in. 76 cm			
Vertical Positioner*	Full Length: 3.5 ft 107 cm Allowance: 18 in. 46 cm			
Hose Size	3/2-8/4			
Pitch Adjustment	0.6–2.5 in. 15–64 mm			

^{*}Custom lengths available. Additional allowance required to complete travel distance.



FIN FAN ACCESSORY CONFIGURATION



A complete Fin Fan Accessory configuration includes the following components:

- 1. FF-100 Fin Fan Clamp Kit
 - a. Hose snout
 - b. 30-inch clamps
 - c. Guide tube assembly
 - d. Scaffold mount
 - e. ABX-2L mounting plate
- 2. Horizontal and vertical drive rails
- 3. Hose collet stops
- 4. Guide tubes

The following items are also required:

- AutoBox ABX-2L
- LWP-500 drive carriages
- Stingers and slim-line couplers (to aid the Banshee tools in spanning across the Fin Fan header box and entering the tubes)

PLEASE NOTE: This product is offered as an accessory to the AutoBox ABX-2L. The required ABX-2L tractor and drive carriages are sold separately.

To configure the Fin Fan Accessory, the following information should be obtained:

RAIL SELECTION

- What is the width of the fin fan exchanger?
 - The horizontal rail will need to be a minimum of 30 inches (76 cm) longer than the fin fan unit to allow the drive carriage to travel the complete distance of the exchanger face.
- What is the height of the fin fan exchanger?

The vertical rail will need to be a minimum of 18 inches (46 cm) longer than the fin fan unit is in height.

HOSE COLLET STOP SELECTION

What is the hose (flex lance) size to be used?

The appropriate hose stop collet/collets (FF 121-XXX) will be required.

GUIDE TUBE SELECTION

What is the ID of the tubes being cleaned? What size BN tools will be used?
 The appropriate size guide tube will be required.

DRIVE CARRIAGES

Will the Fin Fan Accessory be used with an existing ABX-2L and LWP-500?

If customer owns the LWP-500 positioner (or is purchasing one), the stops, horizontal and vertical carriages can be used for the Fin Fan kit. If the customer does not own an LWP-500, the carriages and stops will need to be added as optional items.

STINGERS/COUPLERS

- What is the depth of the header box (distance from outside surface to tube sheet)?
 - The guide tube length will need to be approximately 6–8 inches (15–20 cm) longer than the depth of the header box. The nipple/stinger will need to be about 2 inches (5 cm) shorter than the header box depth.
- What is the hose end fitting size, type, and thread?

ADDITIONAL INFORMATION

 Make sure the hoses (flex lances) to be used are at least 13 ft (4 m) longer than the fin fan heat exchanger to be cleaned.



FIN FAN ACCESSORY CONFIGURATION

ORDERING A FIN FAN ACCESSORY

The Fin Fan Accessory can be configured to specified requirements. Configuration options are described below:

FIN FAN ACCESSORY COMPONENTS		
1 x FF-100 Fin Fan Clamp Kit Includes snout, 30" clamps, guide tube ass	embly, scaffold mount, and mounting plate	
1 x BU 002.1-15 Slotted rail, 15 ft		
1 x BU 002.1-3.5 Slotted rail, 3.5 ft		
2 x FF 121-XXX* Hose Stop, Collet Style		
2 x ABX 11 X-XX* Guide Tube		

^{*}Specify full part ID from options charts

Rail Options

Horizontal and vertical rail lengths are customizable. Contact StoneAge Customer Service for availability.

Hose Stop Collet Sizes

HOSE OD	SPIRSTAR	PARKER	COLLET
0.26-0.38 in.	3/2	2240D-02	FF 121-297
	3/4, 4/2	2240D-025, 2440D-02	FF 121-328
	3/6, 5/2	2240D-03	FF 121-406
0.39-0.50 in.	4/4	2448D-025	FF 121-438
	4/6, 5/4, 6/2	2240D-04	FF 121-460
		2640D-025, 2740D-03	FF 121-484
	6/4	2440D-04	FF 121-516
0.51–0.61 in.	5/6, 8/2	2240D-05, 2740D-03	FF 121-547
	8/4		FF 121-594
		2440D-05	FF 121-625
0.80-0.93 in.	3/8" Rubber WB Hose		N/A

Guide Tube Options

BANSHEE MODEL	TUBE SIZE	TUBE LENGTH	TUBE PART ID
BN9.5	.459"	12.5 in. 316 mm	ABX 115-12
		36 in. 914 mm	ABX 115-36
BN13	.546"	12.5 in. 316 mm	ABX 116-12
		36 in. 914 mm	ABX 116-36
BN15	.674"	12.5 in. 316 mm	ABX 117-12
		36 in. 914 mm	ABX 117-36
BN18	.745"	12.5 in. 316 mm	ABX 119-12
		36 in. 914 mm	ABX 119-36