




# AUTOBOX<sup>TM</sup> (ABX-100-XX) HOSE GUIDE UPGRADE GUIDE



# AUTOBOX™ (ABX-100-XX) HOSE GUIDE UPGRADE PARTS




**ABX-100 8mm UPGRADE** 




#	PART NUMBER	QTY.
1	ABX 113-001 Coupling Assy	2
2	ABX 119-XX Guide Tube, .745 ID	2
3	ABX 120-001 Mounting Bracket, Inside	1
4	ABX 121-547 Hose Stop Collet, .547	1
5	ABX 121-594 Hose Stop Collet, .594	1
6	ABX 121-625 Hose Stop Collet, .625	1
7	ABX 124 Adapter, .745 ID Guide Tube	2
8	ABX 130-001 Quick-Release Pin	1
9	ABX 137-001 Collet Reference Decal	1
14	ABX 291-001 Mounting Bracket	2
15	HS 121-50-56 Hose Stop Clamp Assembly, .5056	2
16	HS 121-56-61 Hose Stop Clamp Assembly, .5661	2

#### **REMOVE THE GUIDE TUBES:**

1. Remove and **RETAIN** two .25-20 X 1.25 SQUARE HEAD CAP SCREWS.




2. Remove Guide Tube with Adapter from the Housing.



# **ABX-2L UPGRADE DISASSEMBLY INSTRUCTIONS**


### REMOVE THE MOUNTING BRACKET ASSEMBLY AND COUPLING ASSEMBLIES:

1. Remove the Mounting Bracket Assembly and Coupling Assemblies and RETAIN ALL SCREWS.



#### **INSTALL THE ABX 137-001 COLLET REFERENCE DECAL:**


1. Clean off the existing Collet Reference Decal with alcohol. Peel the sticker off the back of the ABX 137-001 Collet Reference Decal and place it directly on top of the existing Collet Reference Decal.



# **ABX-2L UPGRADE INSTRUCTIONS ASSEMBLY INSTRUCTIONS**


#### INSTALL THE ABX 113-001 INTO THE ABX 291-001 MOUNTING BRACKET:

1. Insert the two ABX 113-001 COUPLING ASSEMBLIES into the ABX 291-001 Mounting Bracket with the threaded holes facing up as shown below.



#### INSTALL THE ABX 291-001 MOUNTING BRACKET AND ABX 113-001 COUPLING ASSEMBLIES:


1. Install the Mounting Bracket with Couplings Assembly into the main Housing and fasten with the four retained .37-16 X .75" FLAT HEAD CAP SCREWS. Use BLUE LOCTITE 242® OR Equivalent to secure screws in place.



# **ABX-2L UPGRADE ASSEMBLY INSTRUCTIONS**

#### INSTALL THE ABX 124 ADAPTERS ONTO THE ABX-119-XX GUIDE TUBES:


1. Loosen the set screws on the ABX 124 Adapters. Insert the two ABX 119-XX Guide Tubes into the two ABX 124 ADAPTERS. Tighten the set screws on the Adapters to secure the Guide Tubes.



#### INSTALL THE GUIDE TUBE AND ADAPTER ASSEMBLIES INTO THE ABX 113-001 COUPLING ASSEMBLIES:

1. Install the two GUIDE TUBE and ADAPTER ASSEMBLIES into the ABX 113-001 COUPLING ASSEMBLIES. Install the two retained .25-20 X 1.25 SQUARE HEAD CAP SCREWS (X2) and tighten to secure the Guide Tubes in place.





#### **COLLET INSERTION, HOSE, AND HOSE STOP INSTALLATION**

- 1. Remove Quick Release Pin and pull out existing Collet.
- 2. Insert Banshee tool on hose through the AUTOBOX™ (ABX-2L-V2) Hose Tractor, and hose guide assembly. Be sure that the Banshee tool and hose end pass the location of the Collet.
- 3. Select the appropriate Collet for the hoses to be used. (See "Recommended Collets For Common Hose Sizes" plaque on the ABX-100 Hose Guide.)
- 4. Install the Collet and quick release pin.
- Pull on the hoses from the back of the AUTOBOX™ (ABX-2L-V2) Hose Tractor to ensure that the Collet does not allow the Banshee to back out of the Guide or Hose Tractor.
- To install hose stops, push tool through until the tips are 1-2"
   (2.5-5 cm) past the end of the tube bundle. Loosely install the stop, then push toward the mounting bracket and tighten in place.

## AWARNING

Appropriate size Collet selection is **CRITICAL** to ensuring proper anti-withdrawal prevention of the tool.

