

Push 2 / Nuendo Bridge

User Guide & Installation Manual — Version 1.0.6

Compatible with Nuendo 14+ and Cubase 14+ — macOS and Windows

This guide covers installation, configuration, and use of the Push 2 / Nuendo Bridge.

Table of Contents

1. System Requirements
2. Installation — macOS
3. Installation — Windows
4. First Launch
5. Nuendo Configuration
6. Using the Bridge
7. Mixer Modes
8. Sends Mode
9. Inserts Mode
10. Plugin Browser
11. Quick Controls
12. Transport
13. Automation
14. Touchstrip
15. Note Input
16. Control Room
17. Channel Strip
18. Channel EQ Page
19. Setup Page
20. Navigation Page
21. MIDI CC Controller
22. Plugin Mapper
23. Button Reference
24. MIDI Channel Allocation
25. Troubleshooting
26. Support

1. System Requirements

- Ableton Push 2 (USB), Steinberg Nuendo 14+ or Cubase 14+, macOS 11+ or Windows 10/11
- **Standalone app/exe: nothing else to install.** The macOS .app and Windows .exe bundle the Python interpreter, all dependencies and the libusb USB runtime. No Homebrew, no libusb, no Python.
- **Running from source only:** Python 3.9–3.11.9 (3.12/3.13 not yet supported), libusb (macOS: `brew install libusb`), and `push2-python` from source:
`pip install git+https://github.com/ffont/push2-python.git`
- Plugin Mapper (optional): `pip install fastapi uvicorn pedalboard`

***Nuendo 15+ features:** Plugin Browser, DirectAccess insert control and the Channel Strip extended-parameter / EQ-curve pages require API 1.3. All other features work with Nuendo 14+.*

2. Installation — macOS

Option A: Standalone App — Apple Silicon (Recommended)

*The pre-built .app is **Apple Silicon (arm64) only**. On an M1/M2/M3 Mac it bundles everything (Python, all dependencies and the libusb USB runtime) — no Homebrew, libusb or Python required. **Intel Macs:** see **Option B below**.*

- Step 1: Copy Push2 Nuendo Bridge.app to /Applications
- Step 2: The app is **not code-signed**, so macOS Gatekeeper blocks it on first launch. Open Terminal and remove the quarantine flag (match the version in the .app name to your copy):

```
xattr -dr com.apple.quarantine "/Applications/Push2 Nuendo Bridge_v1.0.6.app"
```
- Step 3: Copy Ableton_Push2.js to:
~/Documents/Steinberg/Nuendo/MIDI Remote/Driver Scripts/Local/Ableton/Push2/
Create the Ableton/Push2 folder if it doesn't exist.
- Step 4: Double-click the app. A P2 icon appears in the menu bar.

Option B: Run from Source — Intel Macs

The pre-built .app does not run on Intel Macs. Run from source instead (this also builds an Intel-native .app if you prefer — see the note at the end). Open Terminal:

- Step 1: Install Homebrew if needed — see <https://brew.sh>
- Step 2: Install libusb and Python 3.11 — `brew install libusb python@3.11`
- Step 3: From the project folder, install the dependencies:

```
pip3.11 install -r requirements.txt
pip3.11 install git+https://github.com/ffont/push2-python.git
```

- Step 4 (optional, Plugin Mapper): `pip3.11 install fastapi uvicorn pedalboard`
- Step 5: Copy Ableton_Push2.js to the MIDI Remote folder (see Option A, Step 3).
- Step 6: Run the bridge — `cd src && python3.11 main.py`

To build a standalone Intel .app on an Intel Mac, run `bash scripts/build.sh` (with the dependencies above installed). PyInstaller produces an architecture-native app, so building on Intel yields an Intel .app.

3. Installation — Windows

Windows now ships as a **standalone .exe** — no Python, pip or command line required. See the separate Windows Installation Guide for the step-by-step walkthrough. Key points:

- Download **Push2NuendoBridge-vX.Y.Z-Windows.zip** and unzip it anywhere (e.g. Documents). It contains the .exe, Ableton_Push2.js and the PDF guides.
- Install **loopMIDI** and create the four ports: NuendoBridge In, NuendoBridge Out, BridgeNotes, BridgeNotes In. Set it to start with Windows.
- **Plug in the Push 2** — Windows installs the required USB driver (WinUSB) automatically the first time you connect it. No Zadig, no manual driver step.

Note: the bridge and Ableton Live share the same Push 2 USB connection, so they cannot both control it at the same time — close one to use the other. macOS is not affected. (If Windows ever fails to auto-install the driver, the Windows Installation Guide's Troubleshooting section shows how to force it with Zadig.)

- **Double-click the .exe** to run the bridge — it starts in the **system tray** (icon near the clock), not a console window. Right-click the icon for status, Open Plugin Mapper (<http://localhost:8100>), Show Log and Quit. Run with `--terminal` for the classic console version.

No Python install is needed: the interpreter, all dependencies and the libusb runtime are bundled inside the .exe.

- Copy **Ableton_Push2.js** to the MIDI Remote scripts folder, creating the sub-folders if needed:

```
Nuendo:
C:\Users\<user>\Documents\Steinberg\Nuendo\MIDI Remote\Driver
Scripts\Local\Ableton\Push2\

Cubase:
C:\Users\<user>\Documents\Steinberg\Cubase\MIDI Remote\Driver
Scripts\Local\Ableton\Push2\
```

Replace <user> with your Windows user name. The Local\Ableton\Push2 folders usually do not exist yet — create them.

4. First Launch

Connect Push 2 via USB, launch the bridge, open Nuendo. Menu bar icon: P2 ✓ = connected, P2 ■ = waiting. Click for Start/Stop, Show Logs, Plugin Mapper, Start at Login, Quit.

5. Nuendo Configuration

Automatic setup: Nuendo usually detects the script and assigns its ports on its own.

If the script does not load automatically

- Open any project.
- Studio → MIDI Remote Manager → **Add MIDI Controller Surface**.
- Vendor = **Ableton**, Model = **Push2**.
- MIDI Input = **NuendoBridge Out**, MIDI Output = **NuendoBridge In** (the ports carry the same names as listed here).

Note Input

Set the instrument track's MIDI input to **BridgeNotes** (enable it in MIDI Port Setup if hidden).

Important — avoid doubled notes

- In Studio Setup → MIDI Port Setup, **uncheck “In ‘All MIDI Inputs’” for both Push 2 ports** — “Ableton Push 2” (Live Port) and “Ableton Push 2 User Port”.

If left checked, every pad you play is received twice: once via the bridge's BridgeNotes port and once directly from the Push 2 hardware. Excluding the raw Push 2 ports is standard practice for any control-surface bridge and is permanent once set.

6. Using the Bridge

8 vertical zones on the Push 2 screen. Left/Right = bank by 8 tracks. Shift+Left/Right = nudge by 1 track (Volume/Pan modes).

Button	Mode	Encoders
Mix	Volume	8 track volumes
Mix (again)	Channel Strip	Strip module params
Shift+Mix	Track	Vol+Pan+Sends
Clip	Sends	8 sends
Clip (again)	Pan	8 track pans
Device	Quick Controls	8 QC
Browse	Inserts	Plugin params
Add Device	Plugin Browser	Browse/load plugins
Session	XY pad	Morph 2 track params / CC
Master	Navigation	D-pads: zoom / scroll / markers / nudge

Lower row: Mute toggles Mute/Monitor. Solo toggles Solo/Rec. Shift+Mute/Solo clears all.

7. Mixer Modes

Volume Mode (Mix button)

Shows 8 tracks with volume bars, VU meters, and peak clip indicators. Turn an encoder to adjust volume.

Upper row buttons (above the display):

- Short press = select track
- Shift + press = open Edit Channel Settings for that track
- Long press (1 second) = open instrument UI
- Double press = open Edit Channel Settings

Lower row buttons (below the display):

- Toggle Mute, Solo, Monitor, or Record Arm on the corresponding track
- Press the Mute button to switch between Mute and Monitor mode
- Press the Solo button to switch between Solo and Record Arm mode
- Long press (0.5s) in Mute mode = toggle Monitor on that track
- Long press (0.5s) in Solo mode = toggle Record Arm on that track
- Shift+Mute = clear all mutes (or all monitors in Monitor mode)
- Shift+Solo = clear all solos (or all rec arms in Rec mode)

Pan Mode (Shift+Clip)

Shows 8 tracks with pan position indicators. Turn an encoder to adjust pan.

Track Mode (Shift+Mix)

Combined mode for the selected track: Enc1=Volume, Enc2=Pan, Enc3-8=Sends 1-6.

8. Sends Mode

Press Clip. Encoders = send levels. Upper row = On/Off. Lower row = Pre/Post. Left/Right = navigate tracks.

9. Inserts Mode

List View: Short press upper = params. Long press = open UI. Shift+upper = params+UI. Lower = bypass. Shift+Left/Right = slots 1-8 / 9-16.

Parameter View: Encoders = 8 params. Left/Right = bank/page nav. Lower 1=UI, 2=bypass, 3=deactivate. If mapped: ★ MAPPED indicator.

10. Plugin Browser

Requires Nuendo 15+ (MIDI Remote API 1.3)

Press Add Device to open the browser.

Phase 1 — Slot Selection

The screen shows the insert slots of the selected track.

- Upper row buttons (above the display) = select the target slot
- Left/Right = switch between slots 1-8 and 9-16
- Lower row button 8 = Cancel

Phase 2 — Plugin List

- Encoder 1 = page scroll (8 at a time)
- Encoder 2 = fine scroll (highlight moves within page)
- Upper row = load plugin from that column
- Lower row button 1 = cycle to next collection
- Lower row button 8 / Browse = back / cancel

After loading, the bridge returns to Inserts mode and rescans slots automatically.

11. Quick Controls (Device Mode)

Press Device. 8 Quick Controls of the selected track. Left/Right = navigate tracks.

12. Transport Controls

Button	Function	LED
Play	Playback	White/Green/Purple
Record	Recording	Orange/Blink Red/Solid Red
Fixed Length	Cycle/Loop	
Automate	Automation cycle	White/Green/Red
Metronome	Metronome	LED reflects state

13. Automation

Automate button cycles: Off → Read → Read+Write → Write → Off.

14. Touchstrip

Shift+Layout to cycle: Pitch Bend, Mod Wheel (CC 1), Volume.

15. Note Input

64 pads: Chromatic (default) or Drum (Layout). Scale, Accent, Note Repeat available. Set instrument input to BridgeNotes.

Scale selector (Scale button): pick a musical scale or the **Piano** layout. Piano mode arranges the pads like a piano keyboard — white keys on the lower row of each octave pair, black keys on the upper row, four octaves stacked bottom-to-top, every C in purple. The root is locked to C in Piano mode; use Octave Up/Down to move the whole four-octave block.

16. Control Room

Press User. 4 pages: Main, Phones, Cues, Sources. Master encoder = Main level. User+Master = Phones.

17. Channel Strip

Extended-parameter and EQ-curve control require Nuendo 15+ (API 1.3).

From the Mixer view, press **Mix again** to enter Channel Strip mode. The overview shows the six strip sections as Cubase-coloured banners (Gate, Comp, EQ, Tools, Sat, Limiter) plus PreFilter Phase and PreGain.

Important: a strip module can only be controlled once it has been **activated manually in Nuendo**. Open the channel's strip in the Nuendo mixer and load/enable each module (Gate, Comp, EQ, Tools, Sat, Limiter) you want to use. An empty or disabled strip slot is not exposed to the Push 2 — its banner and encoders stay inactive until you turn the module on in Nuendo.

Overview

- Each banner shows the section colour (dimmed when bypassed) and the loaded plugin variant.
- Lower row 1-6 = Bypass each section (pill/LED amber when bypassed).
- Lower row 7 = PreFilter Phase On/Off. Lower row 8 = Edit Channel Settings (white when the window is open).
- Upper row 1-6 = drill into that module's sub-page.

Module Sub-pages

- 8 encoders control that module's parameters. Parameters beyond Cubase's bank zone are exposed via DirectAccess (e.g. VintageCompressor Ratio & Mix, Tube Compressor Character, DeEsser side-chain filter, Maximizer Release/Recover).
- Lower row = the module's binary toggles (Auto Release, Solo, Diff, etc.) — LEDs follow the on-screen pills.
- Upper row layout: 1 = module name (inactive), 2 = Bypass, 3-5 = variant chips, 8 = back to overview.

Variant chips show the currently loaded plugin. Switching the variant must be done in Nuendo's strip-slot menu — the MIDI Remote API does not allow changing strip-slot plugins from a controller; the chip mirrors the active variant in real time.

18. Channel EQ Page

Drill into the EQ section for an EQ-Eight-style page with a live frequency-response curve.

Encoder	Function
1	Band selector (1-4) — turn to pick the active band
2	Filter Type of the selected band (bands 2-3 are fixed Peak)
3	Frequency of the selected band
4	Q of the selected band
5	Gain of the selected band
6	PreFilter Low-Cut frequency

7	PreFilter High-Cut frequency
8	PreGain

- Lower row 1 = selected band On/Off. Lower 6 = LC On, Lower 7 = HC On, Lower 8 = PreFilter bypass.
- Upper row 2 = EQ section bypass (amber when bypassed). Upper 8 = back.
- The curve combines the 4 EQ bands + PreFilter HC/LC. Numbered circles mark each band at its (freq, gain) point — white when the band is on, grey when off. The curve and markers update live, whether you change a parameter from the Push or directly in Nuendo.

19. Setup Page

Press Setup. The upper-row buttons switch tabs: **MIDI Ctrl**, **Vel Curve**, **CR Knob**, **Pedal 1**, **Pedal 2**, and **About**. Upper-row button 7 is **Reload Script** (re-scan tracks and re-sync the bridge's view of the project), available on every tab. All Setup choices are saved to `~/ .push2bridge/settings.json` and restored on the next launch.

MIDI Ctrl

- Aftertouch mode for the pads: Polyphonic (per-note pressure), Channel (global pressure), or Off.

Vel Curve

- Five velocity-response presets (Linear, Log, Exp, S-Curve, Fixed). In Fixed mode, Encoder 5 sets the fixed velocity value.

CR Knob

- Sets what the Master encoder controls by default — Control Room *Main* or *Phones* level. Holding *Select* always gives the other one.

Pedal 1 / Pedal 2 (Footswitch)

- The Push 2 has two pedal jacks: jack 1 sends CC 64, jack 2 sends CC 69. Each pedal has its own tab. The lower row picks the action — *Sustain* (CC 64 passed through to the instrument), *Play/Stop*, *Play*, *Stop*, *Rec*, *Rec/Stop* (start recording, press again to stop), or *Off* — and lower-row button 8 toggles *Invert* (for normally-closed pedals). Defaults: Pedal 1 = Sustain, Pedal 2 = Play/Stop.

20. Navigation Page

Press the **Master** button to overlay four directional D-pads on the 64 pads, one in each corner: **Zoom** (top-left), **Scroll / cursor** (top-right), **Markers / locators** (bottom-left) and **Nudge** (bottom-right). Each pad has hold-to-repeat. The overlay stays active across the mix pages, so you can navigate the timeline while you keep working — and Note, Scale or Session restore the normal pads.

Showing the legend

- **Hold the Master button** to flash an on-screen legend of the four D-pads (what each direction does). Release Master and the screen returns to the mix while the D-pads stay live. Tap Master any time you need a reminder.

The D-pads drive Nuendo Key Commands via the MIDI Remote script. If a direction does nothing, verify the matching command name in Nuendo's File → Key Commands (names must match your version / language).

21. MIDI CC Controller

Shift+Note. 8 assignable CC faders on BridgeNotes port. Upper row = edit CC number. Lower row = toggle 0/127. Defaults: CC 1,2,7,8,10,11,64,65.

22. Plugin Mapper

Create custom parameter mappings for your plugins. Access via the macOS menu bar / Windows tray (Plugin Mapper) or <http://localhost:8100>. Plugins the scanner can't read (iLok/PACE, Waves shells, Nuendo stock plug-ins) can be captured live from Nuendo with **Shift+Browse**; the **Edit Map** button (Inserts parameter page) opens the Mapper on the selected plugin. Mappings are saved in `~/.push2bridge/mappings/` — after saving, press **■ Reload** (Setup) to pick them up. See the separate Plugin Mapper Guide for details.

All Mapper dependencies are bundled in the standalone .app/.exe — nothing to install. Only source installs need: `pip install fastapi uvicorn pedalboard`.

23. Button Reference

Button	Action	Shift + Button
Mix	Volume mode (press again: Channel Strip)	Track mode
Clip	Sends mode (press again: Pan)	
Device	Quick Controls	
Browse	Inserts mode	Capture params (DirectAccess)
Add Device	Plugin Browser	
Session	XY pad	
Master	Navigation D-pads	
Select	(hold) Master encoder → Phones	
Note	MIDI note pads	MIDI CC controller
Setup	Setup page	
Left/Right	Bank nav (8) / track nav	Nudge (1) in Vol/Pan
Play	Playback	
Record	Record toggle	
Mute	Mute/Monitor	Clear all
Solo	Solo/Rec arm	Clear all
User	Control Room	
Layout	Drum/Chromatic	Touchstrip cycle
Upper (dbl / Shift)	Edit Channel Settings	
Scale	Scale selector	
Accent	Fixed velocity	

Repeat	Auto-repeat	
--------	-------------	--

24. MIDI Channel Allocation

Channel	Usage
1 (0xB0)	Mixer (volume, pan, transport, selection, VU)
2 (0xB1)	Insert plugin parameters
3 (0xB2)	Send levels (selected track)
4 (0xB3)	Insert bypass toggles
5 (0xB4)	Quick Controls
6 (0xB5)	Control Room
7 (0xB6)	Bank zone sends
8 (0xB7)	DirectAccess commands (browser, bypass, edit, strip slot, param-flip, variant)
9 (0xB8)	DirectAccess encoder control (mapped params, strip slots)
16 (0xBF)	Heartbeat

25. Troubleshooting

- **Push 2 not found:** check USB, libusb, close Ableton Live.
- **push2-python error:** install it from source — `pip install git+https://github.com/ffont/push2-python.git`. Use Python 3.11.9 or lower.
- **No Nuendo connection:** check bridge is running; add the surface manually (MIDI Remote Manager → Add, Vendor Ableton / Model Push2).
- **Pads play doubled notes:** uncheck “In ‘All MIDI Inputs’” for the Push 2 Live Port and User Port (Studio Setup → MIDI Port Setup).
- **Channel Strip / EQ curve not working:** requires Nuendo 15+ (API 1.3). Drill into a section once to trigger DA strip exploration.
- **Plugin Mapper not loading:** `pip install fastapi uvicorn pedalboard`.
- **Track names not loading:** navigate Left/Right to refresh.

Logs: macOS — ~/Library/Logs/Push2NuendoBridge.log. Windows — terminal output.

26. Support

Push 2 / Nuendo Bridge is donationware.

- GitHub: <https://github.com/mbourque-mix/Push2Nuendo-Bridge>
- Buy Me A Coffee: <https://buymeacoffee.com/mbourque>
- Issues: <https://github.com/mbourque-mix/Push2Nuendo-Bridge/issues>

Licensed under GPL-3.0. Built with push2-python and the Steinberg MIDI Remote API.