

glasstech, inc.

Service Bulletin

Customer Service Department

TELEPHONE: 419-661-9000 FAX: 419-661-9639

INTERNET: <http://www.glasstech.com>

E-mail: service@glasstech.com

SSC100 HEATING ELEMENT SCR TORQUE SPECIFICATION

Reference 020

The SSC100 heating element SCR's have a specification for the torque to be used on the termination lugs, specifically the X1 terminal.

Note that this maximum tightening torque specification is **50 lb.-in.**(pound-inch).

Also, do not exert excessive downward or twisting force to the X1 terminal when connecting the output cable as it can damage the unit. Damage may be avoided by bracing the bus bar with a suitable tool (locking pliers, etc.) when tightening the lug.

Caution labels are being supplied for installation on all existing SCR units in service. Please install these labels as soon as possible. Future replacement units will have these caution labels on them and this information will be supplied in the manufacturer's manual.