
1 Embedded system is a computing system that is contained in an electronic device. Some examples: 1 clist drive 2 printer 3 scanner 4 tv 5 modern 6 network card 7 ATM 8 Antilock brakes 9 Fax Marhine 10 Home security DINRE cost - one fine monotory cost of designing a system Unit cost - exclude NAE, and is cost of manufacturing each copy of the system. Time - be trafetype - fine reed to build a working version of the system Time-to market - time needed to obve lop a system to the point it can be released and sold to customers Maintainability - ability to modify the system after release, especially by people who client design the gystm. Market window - period that the product will have the highest sales. (3) For each technology this is the volume range: FPGA ! 1 - 1000 with A SIC: 1001 - 30000 Units VLSF : 30001 or more units



B) Ising the simplified wodel and algebraic simplifications, the book determines on fine entry as Wi and belayed entry as 1/2 (w-D+w) (w-D). Using lifetime of 200 weeks and delayed to weeks, the 3 loss would be about 41/2%.