Version: 1.0

Version code: 3516 Date: 2021-12-15

First edition

| D_MB_3516 | File: 0_MB_3516.kicad_sch |
|-----------|---------------------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| L_AP_3516 | File: 1_AP_3516.kicad_sch |

| 2_Audio_3516 | File: 2_Audio_3516.kicad_sch |
|--------------|------------------------------|
| | |
| | |
| | |
| | |
| | |

注意事项:

1、请确保USB输入电压不超过5.4V(绝对最大值),

否则有可能造成PCBA永久损坏。

2、在插拔核心板、线束插头与任何软排线之前,请先切断电源。

NOTICE:

1. Make sure that USB input voltage below 5.4V(absolute max), or the PCBA wolud be damaged by the too high voltage.

2. Please power—off the whole board before insert/remove operation

with the core board or any FPC and connector.



Title: RV_DOCK







