

Technical Note

TN# MCSTN307

Rev# 1.0

Release Date: 2024 / 7 / 3

Category: Software
Support Model: ATC3XXX series

Subject

How to get G-sensor data of ATC3XXX series

Introduction

ATC3XXX series get G-sensor data step

Trouble Shooting Step-by-Step

C file download path:

ftp://nexcommcs image:nexcommcsimage@ftp.nexcom.com.tw/SDK/G-sensor/ATC3XXX series/gsensor atc3xxx.c

1. Compile c file # gcc gsensor_atc3xxx.c and it will create a.out file.

```
🙉 🕮 🗊 root@ai: /home/ai
-rw----- 1 ai
                                192 Jul 14 03:45 .Xauthority
-rw-r--r-- 1 ai
                               2090 May 11 22:48 .xsessionrc
                       ai
root@ai:/home/ai# gcc gsensor_atc3xxx.c
root@ai:/home/ai# ll
total 152
                               4096 Jul 14 03:51 ./
drwxr-xr-x 17 ai ai 4096 Jul 14 03:51 ./
drwxr-xr-x 3 root root 4096 May 11 22:48 ../
-rwxr-xr-x 1 root root 14144 Jul 14 03:51 a.out*
-rw----- 1 ai ai 3351 Jul 16 2023 .bash_history
drwxr-xr-x 17 ai ai
-rw-r--r-- 1 ai ai
-rw-r--r-- 1 ai ai
                                220 May 11 22:48 .bash_logout
                                3771 May 11 22:48 .bashrc
drwx----- 10 ai ai
                               4096 Jul 16 2023 .cache/
                               4096 May 15 21:45 .compiz/
4096 Jul 13 21:07 .config/
drwx----- 3 ai ai
drwx----- 14 ai
                        ai
                                4096 Jul 14 03:48 Desktop/
drwxr-xr-x 3 ai
```

2. Confirm i2c address: # i2cdetect -r -y 8, for example ATC3530 is 6b.



The Intelligent Systems

ATC3540 i2c address is 70.

3. ATC3530

Execute ./a.out ./tmp.log 8, it will shows g-sensor data.

```
root@ai:/home/ai
root@ai:/home/ai# ./a.out ./tmp.log 8
/dev/i2c-8
Initalize LSM6DSL successfully
ACC X:0.02G Y:0.02G Z:1.01G
GYRO X:69 Y:FF15 Z:FFF2
Left the machine for 3 seconds...
ACC X:0.02G Y:0.02G Z:1.02G
GYRO X:B0 Y:FF0F Z:FFF3
Shut down LSM6DSL successfully
```

ATC3540

Execute ./a.out ./tmp.log 7