

Sarasota Memorial Hospital – Venice

SERC Site Handbook

Page 8 of 10 Ver 1.03

KENWOOD TKR-750.850 ALL STAR SETUP

The following is a direct copy from the Plug N Play cable site:

These are the pins used on the repeater interface side of the cable.

- Pin 9 Transmit Audio
- Pin 11 Receive Audio
- Pin 16 PTT
- Pin 19 Ground
- Pin 24 COR logic (Active = high)
- Pin 25 TOR Logic (Active = high)

You will also need to configure your repeater using the configuration software to set the repeater's AUX

Input/Output 5 accessory connector pin #24 as a COR output and the AUX Input/Output 6 accessory pin #25

as a TOR output .

Function Port (AUX Select)

AUX Input/Output 1 AUX Input

AUX Input/Output 2 AUX Input

AUX Input/Output 3 AUX Input

AUX Input/Output 4 AUX Input

AUX Input/Output 5 AUX Output

AUX Input/Output 6 AUX Output

Function Port (AUX Output)

Function Logic Type

AUX Out #1 None

AUX Out #2 None

AUX Out #3 None

AUX Out #4 None

AUX Out #5 None

AUX In/Out 5 COR Active High

AUX In/Out 6 TOR Active High

You will need to disable the repeater's internal timers click on (EDIT). From the drop down box click on (Optional Features). Set the Repeater/EXT-PTT timeout timer to (OFF) and the Repeater Hold Time to (OFF).

To configure the COR and TOR logic active high in your Allstarlink node software you need to make sure of the following settings in your usbradio.conf or simpleusb.conf (what ever channel driver you are using) file which is located in; /etc/asterisk/

Your settings should equal

carrierfrom=usb

ctcssfrom=usb

For HamVOIP Software

Admin Menu

12 Run simpleusb-tune-menu Application

Sarasota Memorial Hospital – Venice

SERC Site Handbook

Page 9 of 10 Ver 1.03

2) Set RX level (adjust using the on screen meter for in between 3 and 5 KHz of deviation)

3) Set Transmit A Level (Set for 3Khz deviation for a 1000 Hz tone)

4) Set Transmit B level to 0

B) Toggle RX Boost Mode (Currently Enabled, you may not need to enable RX boost)

I) Toggle PTT Mode (Currently Active Low)

J) Change COSFORM Mode (Currently "USB")

L) Change CTCSSFORM Mode (Currently "USB")

N) Change RXONDELAY (Currently "3")

W) Write (Save) Current Parameters

0) Exit Menu

On the Admin Menu select Item 15 <reboot this system>

That's about it. Good Luck. 73

Marshall - ke6pcv