

Tolerances:		
.000X	$(= \pm .001)$	
X00.	$= \pm .002$	
.OX	$= \pm .003$	

Clemson University Physics and Astronomy Research Lab

Part: Target Riser	Description: X-Ray Cabinet
Material: 6061-T6	Date: 7/9/2015
Drawn By: Alexander Sheldon	Scale: 1:1