



# Distributed Intelligent Systems – W3 An Introduction to Sensing, Action, and Control in Mobile Robotics



#### Outline



- General concepts
  - Autonomy
  - Perception-to-action loop
  - Sensing, actuating, computing
- Education tools of the course
  - e-puck
  - Webots
- Main example of reactive control architectures
  - Proximal architectures
  - Distal architectures







# General Concepts and Principles for Mobile Robotics





#### Autonomy

- Different levels/degrees of autonomy
  - Energetic level
  - Sensory, motor, and computational level
  - Decisional level
- Needed degree of autonomy depends on task/environment in which the unit has to operate
- Environmental unpredictability is crucial: robot manipulator vs. mobile robot vs. sensor node






### Autonomy – Mobile Robotics

**Task Complexity** 


State of the Art in Mobile Robotics







#### Perception-to-Action Loop







#### Sensors

- Proprioceptive ("body") vs. exteroceptive ("environment")
  - Ex. proprioceptive: motor speed/robot arm joint angle, battery voltage
  - Ex. exteroceptive: distance measurement, light intensity, sound amplitude
- Passive ("measure ambient energy") vs. active ("emit energy in the environment and measure the environmental reaction")
  - Ex. passive: temperature probes, microphones, cameras
  - Ex. active: laser rangefinder, IR proximity sensors, ultrasound sonars





# Classification of Typical Sensors

General classification (typical use)	Sensor Sensor System	PC or EC	A or P
Tactile sensors	Contact switches, bumpers	EC	P
(detection of physical contact or	Optical barriers	EC	A
closeness; security switches)	Noncontact proximity sensors	EC	A
Wheel/motor sensors (wheel/motor speed and position)	Brush encoders	PC	P
	Potentiometers	PC	P
	Synchros, resolvers	PC	A
	Optical encoders	PC	A
	Magnetic encoders	PC	A
	Inductive encoders	PC	A
	Capacitive encoders	PC	A
Heading sensors (orientation of the robot in relation to a fixed reference frame)	Compass	EC	P
	Gyroscopes	PC	P
	Inclinometers	EC	A/P

A, active; P, passive; P/A, passive/active; PC, proprioceptive; EC, exteroceptive.



# Classification of Typical Sensors

General classification (typical use)	Sensor Sensor System	PC or EC	A or P
Ground-based beacons (localization in a fixed reference frame)	GPS Active optical or RF beacons Active ultrasonic beacons Reflective beacons	EC EC EC EC	A A A
Active ranging (reflectivity, time-of-flight, and geometric triangulation)	Reflectivity sensors Ultrasonic sensor Laser rangefinder Optical triangulation (1D) Structured light (2D)	EC EC EC EC EC	A A A A
Motion/speed sensors (speed relative to fixed or moving objects)	Doppler radar Doppler sound	EC EC	A A
Vision-based sensors (visual ranging, whole-image analysis, segmentation, object recognition)	CCD/CMOS camera(s) Visual ranging packages Object tracking packages	EC	P





#### Action - Actuators

- For different purposes: locomotion, control a part of the body (e.g., arm), heating, sound producing, etc.
- Examples of electrical-to-mechanical actuators: DC motors, stepper motors, servos, loudspeakers, etc.





## Computation

- Usually microcontroller-based; extra memory capabilities can be added and multiple microcontrollers are becoming standard
- ADC: Analog-to-Digital Conversion (continuous amplitude and time converted in discrete amplitude and time)
- DAC: Digital-to-Analog Conversion (discrete amplitude and time converted in continuous amplitude and time)
- Different types of control architectures: e.g., reactive ('reflex-based') vs. deliberative ("planning")





## **Sensor Performance**







- Range
  - Upper limit
- Dynamic range
  - ratio between lower and upper limits, usually in decibels (dB for power and amplitude)
  - e.g. voltage measurement from 1 mV to 20 V

$$20 \cdot \log \left[ \frac{20}{0.001} \right] = 86 dB$$

Note: similar to the acoustic amplitude

• e.g. power measurement from 1 mW to 20 W

$$10 \cdot \log \left\lceil \frac{20}{0.001} \right\rceil = 43 dB \qquad P = U \cdot I = \frac{1}{R} U^2$$

Note: 10 instead of 20 because power involves a squared amplitude!!





#### General Sensor Performance

#### Resolution

- minimum difference between two values
- usually: lower limit of dynamic range = resolution
- for digital sensors it is usually the A/D resolution.
  - e.g. 8 bit A/D with upper range of 5V: resolution = 5 / 255

#### Linearity

- variation of output signal as function of the input signal
- linearity is less important when signal is treated with a digital device (e.g., microcontroller, computer)

$$\begin{array}{ll}
x \to f(x) & ? \\
y \to f(y) & \alpha \cdot x + \beta \cdot y \to f(\alpha \cdot x + \beta \cdot y) = \alpha \cdot f(x) + \beta \cdot f(y)
\end{array}$$





#### General Sensor Performance

- Bandwidth or Frequency
  - the speed with which a sensor can provide a stream of readings
  - usually there is an upper limit depending on the sensor and the sampling rate
  - lower limit is also possible, e.g. acceleration sensor
  - frequency response: phase (delay, lag) of the signal and amplitude might be influenced





#### In Situ Sensor Performance

#### Characteristics that are especially relevant for real world environments

- Sensitivity
  - ratio of output change to input change
  - however, in real world environment, the sensor has very often high sensitivity to other environmental changes, e.g. illumination
- Cross-sensitivity (and cross-talk)
  - sensitivity to other environmental parameters
  - influence of other active sensors
- Error / Accuracy
  - difference between the sensor's output and the true value

$$\begin{pmatrix}
accuracy = 1 - v \\
v
\end{pmatrix} error \\
m = measured value \\
v = true value$$





#### In Situ Sensor Performance

#### Characteristics that are especially relevant for real world environments

- Systematic error -> deterministic errors
  - caused by factors that can (in theory) be modeled -> prediction
  - e.g. calibration of a laser sensor or of the distortion cause by the optic of a camera
- Random error -> non-deterministic
  - no deterministic prediction possible
  - however, they can be described probabilistically
  - e.g. gaussian noise on a distance sensor, black level noise of camera
- Precision (different from accuracy!)
  - reproducibility of sensor results

$$precision = \frac{range}{\sigma}$$

 $\sigma$  = standard dev of the sensor noise





# **Educational Tools for This Course**





#### The e-puck Mobile Robot

http://www.e-puck.org/

#### Main features

- Cylindrical, Ø 70mm
- dsPIC processor
- Two stepper motors
- Ring of LEDs
- Many sensors:
  - ✓ Camera
  - ✓ Sound
  - ✓ IR proximity
  - ✓ 3D accelerometer
- Li-ion accumulator
- Bluetooth wireless communication
- Open hardware (and software)










#### e-puck Block Schema

Actuators?

Sensors?

Computation?

Communication?







### Simulation: Why?

- Hardware prototyping is time-consuming and in general more expensive
- Flexibility in the experimental setup
- Easier for monitoring experiments (and evaluating specific metrics)
- Evaluation of algorithms in settings difficult (e.g., very large number of robots) or even impossible (e.g., noise-free sensors) to reproduce in reality
- Predictive value: asking questions in simulation before building hardware






#### Real and Simulated e-puck



Real e-puck




#### Realistically simulated e-puck (Webots)


- intra robot details: discrete sensors, actuators, transceivers, etc.
- noise, nonlinearities of S&A reproduced



#### Webots: High-Fidelity Simulator











In this course, we will focus on steps 2 and 3 only.



#### Webots Features




- As of Jan 2019 open source
- Faithful physics-based robotics simulator
- Tuneable trade-off between faithfulness and computational cost through kinematic (e.g., speed, position) vs. dynamic (e.g., forces, friction, mass) modes
- Fast prototyping; can be interfaced with ROS
- Can usually run faster than real-time
- Available sensors: distance sensors, light sensors, cameras, accelerometers, touch sensors, position sensors, GPSs, receivers, force sensors, etc.
- Available actuators: linear and rotational motors, grippers, LEDs, emitters, etc.



### Webots Principles





The more robots, the slower the simulation!




scene tree

# Webots GUI world view



editor







# **Examples of Reactive Control Architectures**





# Reactive Architectures: Proximal vs. Distal in Theory

#### • Proximal:

- close to sensor and actuators
- very simple linear/nonlinear operators on crude data
- high flexibility in shaping the behavior
- Difficult to engineer in a "human-guided" way;
   machine-learning usually perform better





# Reactive Architectures: Proximal vs. Distal in Theory

- Distal architectures
  - Further from sensor and actuators
  - Self-contained behavioral blocks
  - Less flexibility in shaping the behavior
  - Easier to engineer in a "human-guided" way the basic block (handcoding); more difficult to compose the blocks in the right way (e.g., sequence, parallel, ...)






#### Reactive Architectures: Proximal vs. Distal in Practice

- A whole blend!
- Five "classical" examples of reactive control architecture for solving the same problem: obstacle avoidance.
- Two proximal: Braitenberg and Artificial Neural Network
- Three distal: rule-based and two behavior-based (Subsumption and Motor Schema)





# Ex. 1: Braitenberg's Vehicles




- Work on the difference (gradient) between sensors
- + excitation, inhibition; linear controller (output = signed coefficient \* input)
- Symmetry axis along main axis of the vehicle (----)
- Originally omni-directional sensors but work even better with directional sensors
- Originally: light sensors; works perfectly also with proximity sensors (3c?)





# Examples of Braitenberg's Vehicles




Excitatory connections

Inhibitory connections





# Braitenberg Applied to e-puck



- 2 actuators
- 8 proximity sensors

• Motor speed is a linear combination:


$$\begin{bmatrix} v_{L} \\ v_{R} \end{bmatrix} = \begin{bmatrix} \alpha_{L0} & \alpha_{L1} & \cdots & \alpha_{L7} \\ \alpha_{R0} & \alpha_{R1} & \cdots & \alpha_{R7} \end{bmatrix} \cdot \begin{bmatrix} d_{IR0} \\ \vdots \\ d_{IR7} \end{bmatrix} + \begin{bmatrix} v_{L0} \\ v_{R0} \end{bmatrix}$$
bias



weight



#### Ex. 2: Artificial Neural Network




input

neuron N with sigmoid transfer function f(x)

$$O_i = f(x_i)$$

$$f(x) = \frac{2}{1 + e^{-x}} - 1$$

$$x_{i} = \sum_{j=1}^{m} w_{ij} I_{j} + I_{0}$$







#### Ex. 3: Rule-Based

#### Rule 1:

if (proximity sensors on the left active) then
turn right

#### Rule 2:

if (proximity sensors on the right active) then
turn left

#### Rule 3:

if (no proximity sensors active) then
move forwards






### Subsumption Architecture

- Rodney Brooks 1986, MIT
- Precursors: Braitenberg (1984), Walter (1953)
- Behavioral modules (basic behaviors) represented by Augmented Finite State machines (AFSM)
- Response encoding: predominantly discrete (rule based)
- Behavioral coordination method: competitive (priority-based arbitration via inhibition and suppression)





## Subsumption Architecture




Classical paradigm (serial); emphasis on deliberative control Subsumption (parallel); emphasis on reactive control






## Subsumption Architecture: AFSM







# Ex. 4: Behavior-Based with Subsumption







# Evaluation of Subsumption

- + Support for parallelism: each behavioral layer can run independently and asynchronously (including different loop time)
- + Fast execution time possible
- Coordination mechanisms restrictive ("black or white")
- Limited support for modularity (upper layers design cannot be independent from lower layers).






## **Motor Schemas**

- Ronald Arkin 1987, Georgia Tech
- Precursors: Arbib (1981), Khatib (1985)
- Parametrized behavioral libraries (schemas)
- Response encoding: continuous using potential field analog
- Behavioral coordination method: cooperative via vector summation and normalization






## Motor Schemas







# Ex. 5: Behavior-Based with Motor Schemas







## Visualization of Vector field for Ex. 5

#### Avoid-static-obstacle


$$V_{\text{magnitude}} = \begin{cases} 0 & \text{for} & d > S \\ \frac{S - d}{S - R}G & \text{for} & R < d \le S \\ \infty & \text{for} & d \le R \end{cases}$$

S = obstacle's sphere of influence

 $\mathbf{R}$  = radius of the obstacle

G = gain

**d** = distance robot to obstacle's center








### Visualization of Vector field for Ex. 5

#### Move-to-goal (ballistic)

Output = vector =  $(r, \varphi)$ (magnitude, direction)

 $V_{\text{magnitude}} = \text{fixed gain value}$ 

 $V_{direction}$  = towards perceived goal








### Visualization of Vector field for Ex. 5

#### Move-to-goal + avoid obstacle


Linear combination (weigthed sum)







# Ex. 5: Behavior-Based with Motor Schemas



Adding noise is a simple solution for avoiding to get stuck in local minima using arbitrary vector fields

Alternative more complex approach: use harmonic potential functions (explicitly designed for not generating local minima)





## Evaluation of Motor Schemas

- + Support for parallelism: motor schemas are naturally parallelizable
- + Fine-tuned behavioral blending possible
- Robustness -> well-known problems of potential field approach -> extra introduction of noise or more complex functions
- Slow and computationally expensive sometimes





# Evaluation of both Architectures in Practice

- In practice (my expertise) you tend to mix both and even more ...
- The way to combine basic behavior (cooperative and/or competitive) depends from how you developed the basic behaviors (or motor schemas), reaction time required, on-board computational capabilities, ...





# Conclusion





## Take Home Messages

- Perception-to-action loop is key in robotics, several sensor and actuator modalities
- Key categories for sensor classification are exteroceptive vs. proprioceptive and active vs. passive
- Experimental work can be carried out with real and realistically simulated robots
- A given behavior can be obtained with different control architectures
- Control architectures can be roughly classified in proximal and distal architectures
- Braitenberg vehicles and artificial neural networks are two typical examples of proximal architectures, motor schemas and subsumption are typical example of distal architectures





## Additional Literature – Week 3

#### **Books**

- Braitenberg V., "Vehicles: Experiments in Synthetic Psychology", MIT Press, 1986.
- Siegwart R., Nourbakhsh I. R., and Scaramuzza D., "Introduction to Autonomous Mobile Robots", 2<sup>nd</sup> edition, MIT Press, 2011.
- Arkin R. C., "Behavior-Based Robotics". MIT Press, 1998.
- Everett, H. R., "Sensors for Mobile Robots, Theory and Application", A. K. Peters, Ltd., 1995