
any state other than DISARMED
boot
DISARMED
sensors ignored
ARM button
or remote ARM
EXIT_DELAY
sensors ignored
10 s elapsed
ARMED
PIR and door active
button press
or authenticated remote DISARM
30 s elapsed
PIR rising edge
or door opened
ALARM
siren, red LED
10 s elapsed
ENTRY_DELAY
fast warning beeps
If the door is still open when the exit delay ends,
ENTRY_DELAY starts immediately after ARMED.