

Microcontroller

- A microcontroller (MCU) is a **small computer** on a **single integrated circuit** that is designed to **control specific tasks** within electronic systems. It **combines** the functions of a central processing unit (CPU), **memory, and input/output interfaces**, all on a **single chip**.
- A typical microcontroller consists of a processor core, volatile and non-volatile memory, input/output peripherals, and various communication interfaces.
- The **processor core** is responsible for executing instructions and controlling the other components of the microcontroller.
- The **memory** is used to store data and program code, while the **input/output peripherals** are used to interact with the external environment.
- It is often used as **part of an embedded system** to control specific functions in electronic devices.

In summary, a **microcontroller includes:**


- A **processor** that runs instructions.
- **Memory** to store programs and data.
- **Input/Output ports** to connect with buttons, sensors, screens, etc.
- **Communication ports** (to connect with other devices).

Why Are Microcontrollers Useful?

- They are **programmable**, so you can make them do different tasks.
- **Common programming languages** used are C, C++, and assembly language.
- They are often **low-power**, which is great for devices that run on batteries.
- They are **small, cheap, and perfect** for controlling devices over a long time.
- Most microcontrollers are **embedded**, meaning they are built inside other devices.

The **microcontroller used in Embedded System**. For example:

- Security Systems
- Laser Printers
- Automation System
- Robotics



Working of Microcontroller

Here are the steps of how a Microcontroller works.

- **Initialization:** When powered on, the reset pin initializes the CPU and peripheral circuits to a known state.
- **Instruction Fetching:** The CPU fetches the next instruction from the Program Memory (ROM) using a Program Counter (PC).
- **Instruction Interpretation & Execution:** The CPU decodes the instruction and performs arithmetic, logic, or data transfer operations (e.g., reading a sensor, calculating a value).
- **Peripheral Control:** The CPU uses I/O ports to send signals to external peripherals, such as turning on a motor.
- **Looping:** This process continues in a continuous loop until power is removed or the system is reset.

Microcontroller Properties

- Microcontroller devices are capable of having words longer than 64 bits.
- Microcontroller consist of RAM, ROM, Timer, I/O Ports.
- Microcontroller ROM is used for program storage and RAM is used for data storage.
- It is designed by using CISC architecture.
- The power consumption of modern microcontrollers is significantly lower and have operating voltage range from 1.8V to 5.5V
- The latest feature of microcontroller is flash memory like EPROM and EEPROM.

Uses of Microcontroller

Microcontrollers are used in a wide range of electronic devices and systems.

These are given below:

Everyday Uses of Microcontrollers

- Devices that detect and control light (like automatic street lights).
- Devices that monitor and adjust temperature (like smart thermostats).
- Fire detection and safety systems (like smoke alarms).
- Tools used in factories to measure and monitor things.
- Systems that control industrial processes automatically.

Uses of Microcontrollers in Industrial Control

- Devices that measure and track industrial data.
- Systems that manage and control production processes.

Uses of Microcontrollers in Measuring Devices:

- Voltage meters.
- Devices that count rotating parts (like in motors).
- Current meters.
- Portable measuring tools (like digital multimeters).

Issues in Microcontroller

There are multiple issues that can arise with microcontrollers. The **most common issues** are:

Timing Issues

- Microcontrollers need precise timing to run tasks correctly.
- Any timing errors can cause malfunctions that are often hard to detect and fix.

Power Issues

- They need a stable power supply.
- Power fluctuations or drops can cause the microcontroller to stop working or behave unpredictably.

Heat Issues

- Microcontrollers generate heat during use.
- Too much heat can damage the chip or cause it to fail.
- Caused by poor design, bad cooling, or high room temperatures.

Noise Issues

- Can be affected by electromagnetic interference (EMI) and radio frequency interference (RFI) from nearby devices.
- This can lead to errors or unexpected behaviour.

Code Issues

- The software or code running on the microcontroller may have bugs or errors.
- This can lead to malfunctions or failure of the system.

Security Issues

- Microcontrollers can be hacked or infected with malware.
- Risks include unauthorized access, data theft, or system control by attackers.

Compatibility Issues


- May not work well with other hardware or components.
- Can result in errors or system failures.

Microcontroller vs Microprocessor

Microcontroller	Microprocessor
Microcontrollers are used to execute a single task within an application.	Microprocessors are used for big applications.
Its designing and hardware cost is low.	Its designing and hardware cost is high.
Easy to replace.	Not so easy to replace.
It is built with CMOS technology, which requires less power to operate.	Its power consumption is high because it has to control the entire system.
It consists of CPU, RAM, ROM, I/O ports.	It doesn't consist of RAM, ROM, I/O ports. It uses its pins to interface to peripheral devices.

Types of Microcontrollers

The **types** of microcontrollers are **characterized by the bits, memory/devices, instruction set, and memory architecture.**



Classification of Microcontrollers by Number of Bits

(i) 8-bit Microcontrollers

- The internal bus is 8-bits wide.
- The ALU (Arithmetic Logic Unit) performs operations on 8 bits at a time.
- Example microcontrollers: Intel 8031/8051, PIC1x, Motorola MC68HC11.

(ii) 16-bit Microcontrollers

- The internal bus is 16-bits wide, providing better precision and performance than 8-bit.
- A 16-bit microcontroller can handle a wider range of numbers (0x0000 to 0xFFFF, or 0 to 65535) compared to the 8-bit range (0x00 to 0xFF, or 0 to 255).
- Example microcontrollers: Extended 8051XA, PIC2x, Intel 8096, Motorola MC68HC12.

(iii) 32-bit Microcontrollers

- These microcontrollers use 32-bit instructions for operations.
- Used in advanced applications like medical devices, engine control systems, office machines, and other embedded systems.
- Example microcontrollers: Intel/Atmel 251 family, PIC3x.

Classification of Microcontrollers by Memory Type

(i) Embedded Memory Microcontroller

- All functional blocks are built into the chip.
- Includes program memory, data memory, I/O ports, serial communication, counters, timers, and interrupts.
- Example: 8051 microcontroller (has everything on the chip).

(ii) External Memory Microcontroller

- The microcontroller does not have all functional blocks on the chip.
- Some components, like program memory, need to be connected externally.
- Example: 8031 microcontrollers (does not have program memory on the chip).

Classification of Microcontrollers by Instruction Set

(i) CISC (Complex Instruction Set Computer)

- Allows complex instructions that can do multiple tasks in one command.
- Reduces the need for many simpler instructions.
- Example: CISC systems shorten execution time by reducing the number of instructions in a program.

(ii) RISC (Reduced Instruction Set Computer)

- Simplifies the instruction set, using fewer, simpler commands.
- Allows instructions to work on any register and access program and data simultaneously.
- Shortens execution time by reducing clock cycles per instruction.
- RISC systems generally offer better execution performance compared to CISC systems.

Classification of Microcontrollers by Memory Architecture

(i) Harvard Memory Architecture Microcontroller

- Has separate memory for program and data.
- Allows simultaneous access to both program and data memory, improving efficiency.

- Common in microcontrollers that require faster data processing.

(ii) Von Neumann Memory Architecture Microcontroller

- Uses shared memory for both program and data.
- Simplifies design but can be slower since the program and data share the same bus.


Harvard Architecture

Harvard architecture is a computer design model where **program instructions and data are stored in separate memory units that are accessed through independent buses.** This separation allows the processor to **fetch instructions and access data simultaneously**, which helps **avoid the bottleneck** present in traditional **Von Neumann systems.** In summary,

- Eliminates the Von Neumann bottleneck.
- Faster and predictable performance (suitable for real-time systems).
- Parallel access to both instructions and data.

Working Principle

In Harvard Architecture, **fetching an instruction from instruction memory and reading/writing data from/to data memory happen at the same time** without waiting for one to finish. **Separate buses** prevent the bottleneck that occurs when data and instructions share a path. For example, while **an instruction is being executed**, the **next instruction can be fetched simultaneously**, speeding up processing.



Structure of Harvard Architecture

Buses

Buses are used as **signal pathways**. In Harvard architecture, there are **separate buses for both instruction and data**. Types of Buses:

- **Data Bus:** It carries data among the main memory system, processor, and I/O devices.
- **Data Address Bus:** It carries the address of data from the processor to the main memory system.
- **Instruction Bus:** It carries instructions among the main memory system, processor, and I/O devices.
- **Instruction Address Bus:** It carries the address of instructions from the processor to the main memory system.

Components of Harvard Architecture

Harvard architecture is designed with specific components that handle instruction execution, control, and data communication. These are:

- **Arithmetic and Logic Unit:** The arithmetic logic unit is part of the CPU that operates all the calculations needed. It performs addition, subtraction, comparison, logical Operations, bit Shifting Operations, and various arithmetic operations.
- **Control Unit:** The Control Unit is the part of the CPU that operates all processor control signals. It controls the input and output devices and also controls the movement of instructions and data within the system.
- **Input/Output System:** Input devices are used to read data into main memory with the help of CPU input instruction. The information from a computer as output is given through Output devices. The computer gives the results of computation with the help of output devices.

Application of Harvard Architecture

Harvard architecture is a type of computer design where the memory for instructions and data is kept separate. Here are some applications:

Digital Signal Processors (DSPs)

- Audio and video processing, telecommunications, radar systems, and image processing.
- Texas Instruments TMS320 for hearing aids.

Microcontrollers (MCUs)

- Embedded systems in consumer electronics, automotive systems, IoT devices, and industrial automation.
- PIC in automotive ABS

Network Processors

- Routers, switches, and network security appliances.
- Broadcom StrataXGS


Automotive Systems

- Engine control units (ECUs), advanced driver-assistance systems (ADAS), and infotainment systems.
- NXP S32K for engine control

Von Neumann Architecture

Von Neumann architecture is a computer design where **instructions and data are stored in the same memory space**. This means the **CPU fetches both instructions and data from the same memory, using the same pathways**.

Components of Von Neumann Architecture




The Von Neumann architecture is made up with **three main components**.

- CPU
- Memory
- I/O Devices

CPU (Central Processing Unit)

The central processing unit (CPU) is the **main part** of a computer that controls how it works. It is **made up of the control unit, main memory, and the arithmetic logic unit (ALU)**. The CPU handles instructions from programs, processes data, stores information, and produces results. Without the CPU, a computer cannot perform tasks or run any applications.



Basic CPU structure, illustrating ALU

CU (Control Unit)

The control unit **manages** how the **processor works by sending control signals**. It decides how data should move inside the computer, controls input and output operations, and fetches the instructions from memory for execution.

ALU (Arithmetic and Logic Unit)

The arithmetic and logic unit is the part of the CPU that **handles the calculations and decision-making tasks**. It performs arithmetic operations like addition and subtraction, logical operations such as comparisons, and tasks like shifting bits in data.

Registers

Registers are the **fastest type of memory** located **inside the CPU**. They **temporarily store information** that the **processor is currently working on**, making program execution and operations faster and more efficient. Register serves as the CPU's **primary working memory**. **There are several registers, each of which have specific tasks**. There are:

- **PC (Program Counter):** Keeps track of the address of the next instruction to be executed.
- **IR (Instruction Register):** Holds the current instruction being executed.
- **MAR (Memory Address Register):** Stores the address of the memory location being accessed.
- **MDR (Memory Data Register):** Temporarily holds data being transferred to or from memory.
- **Accumulator:** A register that stores intermediate results of arithmetic and logic operations.
- **General Purpose Registers:** Used for temporary storage of data during processing.

Bus

The bus is a communication system that transfers data, addresses, and control signals between the CPU, memory, and I/O devices. In Von Neumann architecture, a single bus is shared for both data and instructions, which can create a bottleneck (known as the Von Neumann bottleneck).

I/O Bus

- **I/O Interface:** Connects the CPU and memory to input/output devices.
- **Device:** Refers to external hardware like keyboards, monitors, or storage devices.

Key Characteristics

- **Single Memory for Data and Instructions:** Both data and program instructions are stored in the same memory.
- **Shared Bus:** A single bus is used for transferring data, addresses, and control signals, which can limit performance.
- **Sequential Execution:** Instructions are executed one at a time in a sequential manner.

Von Neumann Applications

Von Neumann architecture is the foundation of most modern computing systems, where both instructions and data are stored in the same memory. Here are some applications:

- **Personal Computers and Laptops:** Most PCs and laptops (Intel/AMD) use a shared memory that stores both programs and data, enabling efficient

running of software like Windows and browsers. Example: Intel Core i7, AMD Ryzen processors.

- **Smartphones and Tablets:** ARM-based devices use the shared memory model to support multitasking and power efficiency in apps on iOS and Android. Example: Qualcomm Snapdragon, Apple A-series chips
- **Embedded Systems:** Microcontrollers in cars, IoT devices, and appliances use Von Neumann architecture for simple, cost-effective processing of instructions and data in the same memory. Example Arduino Uno (ATmega328), older ARM Cortex-M designs.
- **Servers and Cloud Computing:** Servers utilize shared memory systems to handle large-scale software and data tasks for services like AWS and Netflix.
- **Gaming Consoles:** Consoles like PS5 and Xbox use unified memory to run game code and manage inputs, enabling smooth gameplay.

8051 Microcontroller Architecture

For many years, the 8051 Microcontroller architecture is **vital and important component** in embedded systems design due to its **common use**. Its strong architecture and multiple uses in a variety of industries from consumer electronics to industrial automation are the main causes of its appeal.

What is 8051 Microcontroller?

An 8051 microcontroller is an **8-bit Harvard architecture** microcontroller and it **consists of a CPU, RAM, ROM, I/O ports, timers, and serial communication ports** all combined on **one chip**.


It can **control simple to highly complex operations** in embedded systems since it can carry out instructions which are retrieved from its internal memory.

Types or Classification of 8051 Microcontroller

- The 8051 Microcontroller family consists of **several variations**, including the **original 8051**, the **8031** (which has less functionality), and the **upgraded 8052**.
- **Each variant** offers a **different peripheral configuration and memory size** to meet the needs of a particular application.

Diagram of 8051 Microcontroller

The following diagram shows the overall idea and working principles of the 8051 Microcontroller.



The **system bus** is used to **connect all of the support devices to the CPU**. The system bus is **operated by bus control signals, a 16-bit address bus, and an 8-bit data bus**. The system bus serves as an interface between the CPU and all other devices, including program memory, ports, data memory, interrupt control, serial interface, and timers.

Components of 8051 Microcontroller

The **internal basic components** of the architecture of the 8051 Microcontroller are **CPU, Memory, Bus, and Oscillator**. Each of these are discussed below.

CPU

The central processing unit (CPU) functions as any processing **machine's brain**. It coordinates and oversees every operation performed by the microcontroller. The user has no control over how the CPU operates. It executes from storage, interprets the program that is kept in ROM, and then carries out its intended function. The CPU controls the many register types that the 8051 microcontroller has to offer.

Interrupts: The interrupt subroutine is called by the microcontroller when a high-priority program requests to access the system buses. This causes interruptions in the program that is now executing. An interrupt can be used to delay the present process using in order to complete a subroutine task and then resume the main program. There are different 8051 microcontroller interrupt types. These are:

- Timer 0 overflow interrupt (T0)
- Timer 1 overflow interrupt (T1)
- External hardware interrupt (INT0)
- External hardware interrupt (INT1)
- Serial communication interrupt (RXD/TXD)

Memory

- To do an operation the microcontroller needed a program. The tasks that the microcontroller is supposed to accomplish are guided by this software. A portion of the on-chip memory was needed for the microcontroller's installed program to be stored.
- Memory was also needed by the microcontroller in order to store operands and data for brief periods of time.
- In addition to 128 bytes of data memory (RAM), the microcontroller 8051 includes 4 KB of code or program memory, or 4 KB ROM.

Bus

A Bus is a collection of wires that is used as a data transfer or communication channel. **Eight, sixteen, or more cables** are included in the various bus arrangement. As a result, **a bus can support 8 bits, or 16 bits total.** There are **two bus types that the 8051 microcontroller uses.** These are:

- **Address Bus:** The 16-bit address bus is a component of 8051 microcontrollers. Transferring data from the central processing unit to memory is its usual use.
- **Data bus:** The data bus of an 8051 microcontroller has eight bits. Transferring data from one peripheral place to another is often the usage for it.

Oscillator

It requires a timer to function because the microcontroller is a digital device. An on-chip **oscillator** is externally linked or connected for the microcontroller to **execute timer functions.** An embedded system is used a microcontroller to control device functionality. The **two 16-bit counters and timers** are operated

by the 8051. The oscillator inside the microcontroller is utilized to operate the timers and counters.


Construction of 8051 Micro Controller

The 8051 Microcontroller, which is made with CMOS technology, combines every part into a single silicon chip for dependability and compactness. These are:

- **Central Processing Unit (CPU):** executes all instructions.
- **Random Access Memory (RAM):** Used to store variables and data.
- Program instructions are stored in **ROM** (Read-Only Memory).
- **I/O Ports:** Device interfaces with outside sources.
- **Timer/Counter:** Produces time lags and tally outside occurrences.
- **Serial Communication Ports:** Enables data communication in serial fashion.

PIN Diagram of 8051 Microcontroller

The pin diagram of 8051 microcontroller looks as follows.



- **Pins 1 to 8:** These pins are known as Port 1. This port doesn't serve any other functions. It is internally pulled up, bi-directional I/O port.
- **Pin 9:** It is a RESET pin, which is used to reset the microcontroller to its initial values.
- **Pins 10 to 17:** These pins are known as Port 3. This port serves some functions like interrupts, timer input, control signals, serial communication signals RxD and TxD, etc.
- **Pins 18 & 19:** These pins are used for interfacing an external crystal to get the system clock.
- **Pin 20:** This pin provides the power supply to the circuit.
- **Pins 21 to 28:** These pins are known as Port 2. It serves as I/O port. Higher order address bus signals are also multiplexed using this port.
- **Pin 29:** This is PSEN pin which stands for Program Store Enable. It is used to read a signal from the external program memory.
- **Pin 30:** This is EA pin which stands for External Access input. It is used to enable/disable the external memory interfacing.
- **Pin 31:** This is ALE pin which stands for Address Latch Enable. It is used to demultiplex the address-data signal of port.
- **Pins 32 to 39:** These pins are known as Port 0. It serves as I/O port. Lower order address and data bus signals are multiplexed using this port.
- **Pin 40:** This pin is used to provide power supply to the circuit.

Advantages and Disadvantages of 8051 Microcontrollers

Advantages

- **Versatility:** Suitable for all type of the functions.
- **Integration:** Every necessary part on a single chip.
- **Economical:** Cost-effective for large-scale manufacturing.
- Particularly **low power consumption** is the design's purpose.
- The **great reliability** of the 8051 Microcontroller is well known.
- It offers an **easy-to-understand instruction set, straightforward programming, and user-friendly development tools.**
- There are **multiple uses** with the advance application.

Disadvantages

- **Limited Processing Capacity:** Unsuitable for intricate calculations.
- **Outdated Interfaces:** Certain versions don't follow contemporary communication guidelines.
- **Ethernet or USB connectivity** are essential advanced peripherals.
- The **instruction set** presents **difficulties for code optimization and programming.**

- **Code development and debugging are challenging** due to the outdated development tools.

Applications of 8051 Microcontrollers

The following industries use the 8051 microcontrollers.

- **Industrial Automation:** 8051 microcontroller is used in the Robotics and control systems.
- **Consumer Electronics:** Microwave ovens, remote controllers are worked using 8051 microcontroller.
- **Automotive:** Dashboard screens and engine control devices.
- **Medical devices:** The infusion pumps, patient monitoring systems are created using 8051 microcontrollers.

Steps to Selecting a Proper Microcontroller

Selecting the right microcontroller for a product can be a daunting task. Not only are there a number of **technical features** to consider, there are also **business case issues** such as cost and lead-times that can cripple a project. At the start of a project there is a great temptation to jump in and start selecting a microcontroller before the details of the system have been hashed out. This is of course a bad idea. Before any thought is given to the microcontroller, the hardware and software engineers should work out the **high levels of the system, block diagram and flowchart** them and only then is there enough information to start making a rational decision on microcontroller selection. When that point is reached, there are 10 easy steps that can be followed to ensure that the right choice is made.

Step 1: Make a List of Required Hardware Interfaces

Using the general hardware block diagram, make a list of all the external interfaces that the microcontroller will need to support. There are two general types of interfaces that need to be listed. The first are **communication interfaces**. These are peripherals such as USB, I2C, SPI, UART, and so on. Make a special note if the application requires USB or some form of Ethernet. These interfaces greatly affect how much program space the microcontroller will need to support. The second type of interface is **digital inputs and outputs, analog to digital inputs, PWM's, etc.** These two interface types will dictate the number of pins that will be required by the microcontroller. Figure 1 shows a generic example of a block diagram with the i/o requirements listed.




Figure 1: List of Hardware Features

Step 2: Examine the Software Architecture

The software architecture and requirements can greatly affect the selection of a microcontroller. **How heavy or how light the processing requirements** will determine whether you go with an **80 MHz DSP or an 8 MHz 8051**. Just like with the hardware, make notes of any requirements that will be important. For example, do any of the algorithms require floating point mathematics? Are there any high frequency control loops or sensors? Estimate how long and how often each task will need to run. Get an order of magnitude feel for how much processing power will be needed. The amount of computing power required will be one of the biggest requirements for the architecture and frequency of the microcontroller.

Step 3: Select the Architecture

Using the information from steps 1 and 2, an engineer should be able to start getting an idea of the architecture that will be needed. Can the application get by with **8-bit architectures**? How about **16 bits**? Does it require a **32-bit Arm core**? Between the application and the required software algorithms these

questions will start to converge on a solution. Don't forget to keep in mind **possible future requirements and feature creep**. Just because you could currently get by with an 8-bit microcontroller doesn't mean you shouldn't consider a 16-bit microcontroller for future features or even for ease of use. Don't forget that microcontroller selection can be an iterative process. You may select a 16-bit part in this step but then in a later step find that a 32-bit Arm part works better. This step is simply to start getting an engineer to look in the right direction.

Step 4: Identify Memory Needs

Flash and RAM are two very critical components of any microcontrollers. **Making sure that you don't run out of program space or variable space** is undoubtedly of highest priority. It is far easier to select a part with too much of these features than not enough. Getting to the end of a design and discovering that you need 110% or that features need to be cut just isn't going to fly. After all, you can **always start with more and then later move to a more constrained part** within the same chip family. Using the software architecture and the communication peripherals included in the application, an engineer can estimate how much flash and RAM will be required for the application. Don't forget to leave room for feature creep and the next versions! It will save many headaches in the future.

Step 5: Start Searching for Microcontrollers

Now that there is a better idea of what the required features of the microcontroller will be the search can begin! One place that can be a good place to start is with a **microcontroller supplier** such as Arrow, Avnet, Future Electronics or similar. Talk with an FAE about your application and requirements and often times they can direct you to a new part that is cutting edge and meets the requirements. Just keep in mind that they might have pressure on them at that time to push a certain family of microcontrollers!

The next best place to start is with a **silicon provider** that you are already familiar with. For example, if you have used Microchip parts in the past and had a good experience with them, then start at their website. Most silicon providers have a search engine that allows you to enter your peripheral sets, I/O and power requirements and it will narrow down the list of parts that match the criteria. From that list the engineer can then move forward towards selecting a microcontroller.

Step 6: Examine Costs and Power Constraints

At this point the selection process has revealed a **number of potential candidates**. This is a great time to **examine the power requirements and cost**

of the part. If the device will be powered from a battery and mobile, then making sure the parts are low-power is absolutely precarious. If it doesn't meet power requirements then keep weeding the list down until you have a select few. Don't forget to examine the piece price of the processor either. While prices have steadily been approaching \$1 in volume for many parts, if it is highly specialized or a high-end processing machine then price might be critical. Don't forget about this key element.

Step 7: Check Part Availability

With the list of potential parts in hand, now is a good time to start checking on how available the part is. Some of the things to keep in mind are **what the lead times for the part?** Are they kept in stock at multiple distributors or is there 6-12 week lead time? What are your requirements for availability? You don't want to get stuck with a large order and have to wait three months to be able to fill it. Then there is a question of **how new the part is and whether it will be around for the duration of your product life cycle.** If your product will be around for 10 years then you need to find a part that the manufacturer guarantees will still be built in 10 years.

Step 8: Select a Development Kit

One of the best parts of selecting a new microcontroller is **finding a development kit to play with and learn the inner working of the controller.** Once an engineer has settled their heart on the part they want to use, they should research what development kits are available. If a development kit isn't available then the selected part is most likely not a good choice and they should go back a few steps and find a better part. Most development kits today cost under \$100. Paying any more than that (unless it is designed to work with multiple processor modules) is just too much. Another part may be a better choice.

Step 9: Investigate Compilers and Tools

The selection of the development kit nearly solidifies the choice of microcontroller. The last consideration is to **examine the compiler and tools** that are available. Most microcontrollers have a number of choices for compilers, example code and debugging tools. It is important to make sure that all the necessary tools are available for the part. Without the right tools the development process could become tedious and expensive.

Step 10: Start Experimenting

Even with the selection a microcontroller nothing is set in stone. Usually, the development kit arrives long before the first prototyped hardware. Take advantage by **building up test circuits and interfacing them to the microcontroller**. Choose high risk parts and get them working on the development kit. It may be that you discover the part you thought would work great has some unforeseen issue that would force a different microcontroller to be selected. In any event, early experimentation will ensure that you made the right choice and that if a change is necessary, the impact will be minimal!

System on a Chip (SoC)

A System on a Chip (SoC) in an embedded system is an **integrated circuit** that **consolidates all required computer components** (processor, memory, I/O, and peripherals) **onto a single chip**. It acts as the **"brain" of devices**, providing high performance, low power consumption, and compact size by eliminating multiple separate chips.

Key Components of a SoC

- **Processor Core(s):** Contains one or more Microcontroller (MCU), Microprocessor (MPU), or DSP.
- **Memory:** Integrated RAM and ROM for storage.
- **Peripherals:** Includes USB, UART, SPI, I2C, and GPIOs.
- **Graphics & Audio:** Often includes GPU or Digital Signal Processors.

Advantages in Embedded Systems

- **Reduced Size:** Ideal for wearables and IoT devices, lowering physical footprint.
- **Power Efficiency:** Highly efficient for battery-operated devices.
- **Cost-Effectiveness:** Reduces bill of materials (BOM) cost by replacing multiple chips.
- **Improved Reliability:** Fewer interconnections lead to higher durability.

Uses of SoC

- Used in smartphones, smartwatches, tablets, and computers.
- Internet of Things applications such as home automation.
- Embedded systems applications especially where the microcontroller is used.

SoC vs. Other Technologies


- **Microcontroller:** A simple MCU is technically a type of SoC, but "SoC" usually implies a more complex system with advanced processing capabilities and often a complex operating system (like Linux).
- **System on Module (SOM):** A SOM is a board-level component containing a SoC and other components (RAM/Flash) on a small, pluggable module.

Main Challenges

- **Design Complexity:** High complexity in integrating multiple systems.
- **Reduced Modularity:** Unlike board-level systems, components cannot be individually replaced.

Architecture of SoC

The basic architecture of SoC is shown in the below figure which includes a processor, DSP, memory, network interface card, CPU, multimedia encoder/decoder, DMA, etc. Each part is explained in details below.



- **Processor:** It is the heart of SoC. Usually, SoC contains at least one or more than one coprocessor. It can be a microcontroller, microprocessor, or DSP. Most of the time DSP is used in every SoC as a processor.
- **DSP:** DSP stands for Digital Signal Processor. It is included in SoC to perform signal processing operations such as data collection, data processing, etc. It is also used for the purpose of decoding the images.

- **Memory:** Memory is used in SoC for the purpose of storage. It may be a volatile or non-volatile memory. Volatile memory includes RAM. There are two types of RAMs: one is SRAM and another is DRAM. The non-volatile memory includes ROM.
- **Encoder/Decoder:** Used for the purpose of interrupting information and converting it into codes.
- **Network Interface Card:** SoC has an internal interface or bus or network to connect all individual blocks. Basically, the network interface card provides a connection of the network to the system.
- **GPU:** GPU stands for Graphical Processing Unit, used in SoC to visualize the interface. GPU is specially designed to speed up the operations related to image calculations. The basic blocks of the GPU are the Bus interface, Power Management Unit, Video Processing unit, Graphics Memory Controller, Display interface, etc.
- **Peripheral devices:** Externally connected devices/interfaces such as USB, HDMI, Wi-Fi, and Bluetooth are included in peripheral devices. This device is used in SoC to perform various operations.
- **UART:** Universal Asynchronous Receiver Transmitter is included in SoC which is used to transmit or receive serial data.

Voltage regulators, Oscillators, clocks, and ADC/DAC are also part of SoC.

Memory in Embedded Systems Hardware

In the world of embedded systems, **memory isn't just a place to store files—it's the backbone of system performance, power consumption, and reliability.** Unlike a PC where you can just "add more RAM," **embedded memory is often constrained** by the physical limits of the microcontroller (MCU) or System-on-Chip (SoC).

The Memory Hierarchy

Memory in embedded systems is **organized based on speed, cost, and volatility.** The **closer the memory is to the CPU core, the faster and more expensive it becomes.**

- **Registers:** Internal to the CPU; fastest access.
- **Cache (L1/L2):** High-speed SRAM used to reduce the average time to access data from main memory.
- **Internal Memory:** On-chip Flash and RAM (integrated into the MCU).
- **External Memory:** Off-chip components (SDRAM, Nor Flash, SD Cards) connected via buses like SPI, I2C, or Parallel.

Volatile Memory (RAM)

Volatile memory requires power to maintain the stored information. If the **power goes out**, the **data is lost**.

Static RAM (SRAM)

- **Mechanism:** Uses flip-flops (typically 6 transistors per bit) to store data.
- **Characteristics:** Very fast, low power consumption during standby, but physically large (low density).
- **Embedded Use:** Typically used for internal MCU registers, stack, and heap.

Dynamic RAM (DRAM)

- **Mechanism:** Stores data in capacitors. Because capacitors leak charge, they must be "refreshed" thousands of times per second.
- **Characteristics:** Much denser and cheaper than SRAM but slower and requires a complex memory controller.
- **Embedded Use:** Common in high-end embedded systems (e.g., Raspberry Pi, Medical Imaging) where large amounts of workspace are needed.

Non-Volatile Memory (NVM)

NVM **retains data** even when **power is removed**. This is **where your code (firmware) lives**.

ROM (Read-Only Memory)

- **Mask ROM:** Programmed during chip fabrication. Permanent and unchangeable.
- **OTP (One-Time Programmable):** Can be programmed once by the user, often used for security keys.

Flash Memory

The **industry standard for storing firmware**. It is a **type of EEPROM** that is erased in blocks.

- **NOR Flash:** Supports Execute-In-Place (XiP). The CPU can fetch instructions directly from Flash without copying them to RAM first. It is reliable but slower to write.

- **NAND Flash:** High density and fast write/erase speeds. However, it cannot be used for XiP and requires error correction (ECC). Used for mass storage (e.g., logging data).

Key Concepts in Memory Management

The Memory Map

Every embedded system has a Memory Map, which is a **table or diagram showing** how the **CPU's address space** is allocated. Example: An ARM Cortex-M might map Flash starting at 0x0000\0000 and SRAM starting at 0x2000\0000. It includes:

- **Code Space:** Where the Flash resides.
- **Data Space:** Where the SRAM resides.
- **Peripherals:** Memory-mapped I/O (GPIO, UART, Timers) are often accessed as if they were memory addresses.

The Stack vs. The Heap

- **The Stack:** Stores **local variables and function return addresses**. It grows and shrinks automatically (Last-In, First-Out).
- **The Heap:** Used for **dynamic memory allocation** (e.g., malloc in C). In embedded systems, the **heap is often avoided or strictly controlled** to prevent memory fragmentation.

Memory Protection Unit (MPU)

A hardware component that **monitors memory bus transactions**. It prevents a **"buggy" part** of the code from writing into restricted areas (like the kernel space or configuration registers), which is vital for safety-critical systems.

On-chip vs. Off-chip

Most modern microcontrollers (MCUs) have **integrated Flash and SRAM on the same chip (on-chip)** for speed and small form factor. External memory is used when higher capacity is needed.

Design Considerations for Engineers

When selecting or configuring memory for a project, **consider these "Big Three" trade-offs**. These are:

- **Power Consumption:** DRAM requires constant refreshing (high power), whereas SRAM is efficient but expensive.
- **Latency:** Can the memory keep up with the CPU clock? If not, the CPU must insert "Wait States," which wastes processing cycles.
- **Endurance:** Flash memory has a finite number of Write/Erase cycles (typically 10k to 100k). For frequent data logging, developers use Wear Leveling algorithms to spread the wear across the chip.

Memory Organization and Addressing

Embedded **processors interact with memory through a specific architecture.** The two primary models are:

Feature	Harvard Architecture	Von Neumann Architecture
Buses	Separate buses for Instruction and Data.	Single bus for both Instruction and Data.
Performance	Faster; can fetch code and data simultaneously.	Slower due to "bottleneck" on the single bus.
Usage	Most modern MCUs (ARM Cortex-M).	Older architectures or high-end DSPs.

Performance and Usage Trade-offs

- **SRAM** is **faster** but **expensive** and consumes **more power** per bit.
- **Flash** provides **long-term storage** but has **limited erase cycles**.
- **DRAM** is essential for **high-capacity** requirements but **adds complexity** due to the need for a memory controller.