

## INSTALLATION PROCEDURE

This procedure is to be followed by the person installing the shower screen.

It is imperative that, If issue identified, stop and contact FSO on 1300 40 20 39 before proceeding

Failure to follow this procedure may impact upon your ability to make a warranty claim.

This procedure is supplementary to trade practises for installation and is **not intended to be a "how to install".** 

The installer is responsible for determining the appropriate detailed technique and method of installation.

1 The installer shall be a suitably experienced person to install this shower screen. If you are not suitably experienced, we recommend that you engage such a person to carry out the installation on your behalf.

- **2** Set out the installation and survey the vertical and horizontal planes of the existing structure.
- **3** Survey the panels for dimension and square in all directions.
- **4** Evaluate the suitability of the supplied panels for the specific situation.
- 5 If issue identified, stop and contact FSO on 1300 40 20 39 before proceeding
- 6 Confirm that fixing locations in the structure provide adequate structural fixing for brackets to support panels.
- 7 If issue identified, stop and contact FSO on 1300 40 20 39 before proceeding
- 8 Mark out and drill for fixings.

- **9** Install panels and hardware, packing joint to floor with clear packers as supplied (if the shower is treated with Enduroshield, ensure that the side showing the Enduroshield label side of the glass faces the inside of the shower. Confirm that all panels carry the Eduroshield label).
- 10 If issue identified, stop and contact FSO on 1300 40 20 39 before proceeding
- 11 Adjust panels to allow for required gaping between panels.
- 12 Determine the shower's suitability to function properly and safely without a brace (supplied without brace).
- 13 If issue identified, stop and contact FSO on 1300 40 20 39 before proceeding
- 13 Adjust panels to allow for appropriate silicone joint between panels and structure.
- 14 Cut and silicone the floor dome in location. Cut and fit the seal strip (if your screen comes with these).
- **15** Apply suitable silicone sealant to joints. Note; It is recommended that a neutral cure structural glazing silicone is used.
- **16** Do not allow use of the shower until silicone has cured (time will depend on silicone type used, thickness and weather conditions).
- 17 Dispose of packaging. Please recycle the cardboard.