## RESTRICTED

## **CHAPTER-22**

## BITUMINOUS FLEXIBLE PAVEMENT CONSTRUCTION- METHOD SECTION 93-GENERAL

- 2201. Care must be taken in bituminous work to heat the binder to the correct temperature range; overheating may cause burning or oxidization of the bitumen. Temperature control in heating and during application is not so critical. With cut back as with straight-run bitumen's.
- 2202. Bituminous material must be laid in consolidated before it goes off (sets). This calls for skill and good organization.
- 2203. Recommended specifications for the various type of construction are given in succeeding sections