RESTRICTED

SECTION 132 - APPROACHES TO BRIDGES AND CULVERTS

- 2825. The layout and marking of approaches to bridges are dealt with in RESPB No 3. Section 60.
- 2826. Approaches to bridges and culverts are liable to congestion and to considerable wear. Sight distance, case of gradient, width, and a sound, non-skid surface are particularly important.
- 2827. Approaches always tend to cut up unless they are well built, properly drained, and adequately maintained. Points to remember are:
 - a. When preparing the formation, remove all silty or clayey material, and ensure that the subgrade is sound.
 - b. Use selected material for filling, especially for fills behind abutments, and ensure that the fill is very thoroughly compacted in layers.
 - c. Provide ample side drains, and generous outfall. If the approach is on a downgrade, ensure that surface water cannot run down the road.
 - d. Use the best available surfacing and ensure that there is no ridge or dip at the junction with bridge decking etc.
 - e. Organize the supply of materials and labor for regular maintenance and for immediate repairs in the event of any damage.